**Safety Guide** 

安全指南

安全指南

EN

Caution

To avoid electrical shock, do not open the enclosure.

Use of controls or adjustments or performance of

procedures other than those specified herein may result

The use of optical instruments with this product will

This appliance is classified as a CLASS 1 LASER product under

A very small percentage of individuals may experience epileptic

seizures or blackouts when exposed to certain light patterns or flashing lights. Exposure to certain patterns or backgrounds on a

seizures or blackouts in these individuals. These conditions may

trigger previously undetected epileptic symptoms or seizures in

of any kind, consult your physician before playing.

television screen or when playing video games may trigger epileptic

persons who have no history of prior seizures or epilepsy. If you, or

invone in your family, has an epileptic condition or has had seizure

**IMMEDIATELY DISCONTINUE** use and consult your physician before

RESUME GAMEPLAY ONLY ON APPROVAL OF YOUR PHYSICIAN.

Use and handling of video games to reduce the likelihood of a

• Use in a well-lit area and keep as far away as possible from the

• Avoid large screen televisions. Use the smallest television screen

• Avoid prolonged use of the PlayStation®4 system. Take a 15-minute

Some people may experience discomfort (such as eye strain, eye

discomfort you should immediately discontinue use of your television

stereoscopic 3D games. The length and frequency of necessary breaks may vary from person to person - please take breaks that are long enough to allow any feelings of discomfort to subside. If symptoms

The vision of young children (especially those under 6 years old) is still

you consult with a doctor (such as a pediatrician or eve doctor) before

3D games. Adults should supervise young children to ensure they

Radio waves may affect electronic equipment or medical devices (for

example, pacemakers), which may cause malfunctions and possibl

If you use a pacemaker or other medical device, consult your doctor

or the manufacturer of your medical device before using the wireless networking feature (Bluetooth<sub>®</sub> and wireless LAN).

• Do not use the wireless networking feature in the following

Areas where wireless network use is prohibited, such as ir

- Areas near fire alarms, automatic doors and other types of

PS4<sup>™</sup> system and DUALSHOCK<sub>®</sub>4 wireless controller compliance

hospitals. Abide by medical institution regulations when using

follow the recommendations listed above. When using any 3D

enabled device with your PS4™ system you should read the

llowing a young child to watch 3D video images or play stereoscopic

ony Interactive Entertainment recommends that all viewers take

regular breaks while watching 3D video images, or playing

fatigue, or nausea) while watching 3D video images or playing stereoscopic 3D games on 3D televisions. If you experience such

resuming gameplay if you or your child experience any of the following health problems or symptoms:

Refer servicing to qualified personnel only.

in hazardous radiation exposure.

CLASS 1 LASER PRODUCT

LASER KLASSE 1 PRODUKT

Photosensitivity/Epilepsy/Seizures

increase eye hazard.

IEC60825-1:2007, 2014.

dizziness,

altered vision

disorientation

seizures, or

eye or muscle twitches,

any involuntary movement or convulsior

loss of awareness,

elevision screen

3D images

break during each hour of play.

until the discomfort subsides.

persist, consult your doctor.

instruction manual for that device.

the system on their premises.

automated equipmen

with IMDA standards

Complies with

IMDA Standard

DB102988

Radio waves

locations

injuries

under development. Sony Interactive Entertai

Avoid playing when you are tired or need sleep.

CUH-7106B

4-724-476-21(2)

Before using this product, carefully read this manual and retain it for

future reference. Parents and guardians of children should read this

manual and make sure that the child follows all safety precautions.

This product has been designed with the highest concern for safety.

• Stop use, unplug the AC power cord from the electrical outlet and

• Do not use the system in a closed cabinet or other locations where

If the system's internal temperature becomes elevated, a message

will be displayed. In this case, turn off the system and leave it unused for a while. After the system cools down, move it to a location with good ventilation, and then resume use.

• Use in a well-lit area and keep as far away as possible from the

Avoid prolonged use of the PS4<sup>™</sup> system and wireless controller.

Stop using the system immediately if you begin to feel tired or if you

the wireless controller. If the condition persists, consult a doctor

If you experience any of the following health problems, discontinue

use of the system immediately. If symptoms persist, consult with

· Keep the system, accessories, and any small components out of the

• Keep this product out of the reach of small children. Small children

Make sure the AC power cord is unplugged from the electrical outlet before you connect the HDMI cable.

Any TV or component connected to the system must be functioning

properly and free of defects. If a TV or component connected to the system is faulty or defective, it may cause damage to the TV or component, or to the system itself. As with all electrical products,

connection to faulty or defective components, or the failure to connect to a properly wired outlet, may cause sparking and pose a

• Do not touch the system or connected cables or accessories during

• Do not allow liquid, small particles or other foreign objects to get

Do not expose the system or accessories to dust, smoke or steam. Also, do not place the system in an area subject to excessive dust or cigarette smoke. Dust build-up or cigarette smoke residue on the internal components (such as the lens) may cause the system to

• Do not expose the system or accessories to high temperatures, high

position. When setting the system in the vertical position, use the

Be careful when carrying the system. If you do not have a good grip,

• Do not turn off the system while data is being saved on or loaded

• Do not remove the AC power cord from the electrical outlet until the

while the power indicator is lit or blinking, data may be lost or

indicator is lit or blinking. Data may be lost or corrupted, or the

• Do not stand on or put objects on the system, and do not stack the

• Do not place the system and connected accessories on the floor or

• Do not allow bodily contact with the system or air from the system

• When connecting the system to a plasma or projection\* TV, do not

leave a still image on the TV screen for an extended period of time.

• Permanent hearing loss may occur if the headset or headphones are

vents for an extended period of time while in use. Extended contact

in a place where they may cause someone to trip or stumble.

under these conditions may cause low-temperature burns.

as this may leave a faint image permanently on the screen. \* Except LCD screen types

nsure safe and responsible Internet usage.

Parents are encouraged to monitor children in online activities to

• Do not move the system or adjust its position when the power

power indicator has turned off. If you disconnect the AC power cord

• Do not touch the connectors of the system or accessories.

humidity or direct sunlight.Do not place the system or accessories on surfaces that are

• Do not set the system other than in the vertical or horizonta

the system may drop causing potential damage or injury.

vertical stand (sold separately) for this model of the system.

• Do not use the system or accessories near water.

may swallow small parts or may wrap the cables around themselves, which may inflict injury or cause an accident or a

experience discomfort or pain in your hands or arms while operating

- Dizziness, nausea, fatigue or symptoms similar to motion sickness

- Discomfort or pain in a part of the body, such as eyes, ears, hands

heat may build up. Doing so may cause the system to overheat and

an abnormal manner, produces unusual sounds or smells or

· For more information on product safety and support, visit our

disconnect any other cables immediately if the device functions in

causing fire, electrical shock or personal injury. To help ensure accident-free operation, follow these guidelines:

• Observe all warnings, precautions, and instructions.

• Regularly inspect the AC power cord for damage.

omes too hot to touch.

Use and handling

ision screei

reach of small children.

n electrical storm.

malfunction.

into the system or accessories.

unstable, tilted or subject to vibration.

corrupted, or the system may be damaged.

from the hard disk drive.

system may be damaged

tem with other devices

your doctor

malfunction.

website (•• Further information"

may lead to fire, injury or malfunction.

However, any electrical device, if used improperly, has the potential for

Safety

The connected USB device is not compatible with the system.

- Too many USB devices are connected to the USB hub

### DUALSHOCK<sub>®</sub>4 wireless controller use\*

 Do not handle damaged or leaking lithium-ion batteries. If the internal battery fluid leaks, stop using the product immediately and contact technical support for assistance. If the fluid gets on to your clothes, skin or into your eyes, immediately rinse the affected area with clean water and consult your physician. The battery fluid can cause blindness

- Stop using the system immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms while operating the wireless controller. If the condition persists, consult a doctor. The vibration function of the wireless controller can aggravate injuries. Do not use the vibration function if you have any ailment or injury to the bones, joints or muscles of your hands or arms. If you have an ailment or an injury, do not use the wireless controller to play software titles that contain the vibration function unless you
- first disable this function. Avoid prolonged use of the wireless controller. Take a break at about 30-minute intervals. Note that some software titles enable the vibration function by default. To disable the vibration function, Select  $\bigoplus$  (Settings) >

[Devices] > [Controllers] from the function screen, and then remove the checkmark from [Enable Vibration]. • When using the motion sensor function of the wireless controller, be

- cautious of the following points. If the controller hits a person or object, this may cause accidental injury or damage. Before using check that there is plenty of space around you
- When using the controller, grip it firmly to make sure it cannot slip out of your hand.
- If using a controller that is connected to the PS4<sup>™</sup> system with a USB cable, make sure there is enough space for the cable so that the cable will not hit a person or object. Also, take care to avoid pulling the cable out of the PS4<sup>™</sup> system while using the controller Some PlayStation®, PlayStation®2 and PlayStation®3 system peripherals such as the analog controller (DUALSHOCKs), the analog controller (DUALSHOCKs2) and the DUALSHOCKs3 wireless controller are not compatible with the PS4<sup>™</sup> system.

 Do not stare at the light bar on the controller when it is blinking. If you experience discomfort or pain anywhere in or on your body from light stimulation, discontinue use immediately Charge in an environment where the temperature range is between

10 °C and 30 °C. Charging may not be as effective when performed • The battery has a limited lifespan. Battery duration will gradually

decrease with repeated usage and age. Battery life also varies depending on the storage method, usage state, environment and When the wireless controller is not used for an extended period of

time, it is recommended that you fully charge it at least once a year in order to maintain battery functionality. These notes may also apply to other controllers

### Vents

Do not block any vents. To maintain good ventilation, follow the

- elines below Place the system at least 10 cm away from a wall surface
- Do not place on a carpet or rug with long fibers.
- Do not place in a narrow or cramped space. • Do not cover with cloth.

• Do not allow dust to build up on the vents.

### AC power cord use

- Do not plug the AC power cord for the system into an electrical outlet until you have made all other connections. Make sure the TV ponent is unplugged from the electrical outlet prior to or other com connecting it to the system.
- To help ensure safe operation, regularly inspect the AC power cord. If damaged, stop use immediately and contact Customer Ser Hotline (\*• "Further information").
- Do not use a power cord other than the supplied AC power cord. Do not modify the cord.
- Do not touch the plug of the AC power cord with wet hands. • Protect the AC power cord from being walked on or pinched particularly at plugs, expansion receptacles and the point where the cord exits from the system.
- Do not place heavy items on the cord.
- Do not allow dust or foreign matter to build up around the AC IN connector. Before connecting or plugging in the AC power cord, check that there is no dust or foreign matter in or on the power plug or connecting end of the cord, the electrical outlet or the AC IN connector on the system rear. If the plug or connector becomes dirty, wipe off with a dry cloth before connecting.
- Do not place the AC power cord near heating equipment and do not expose the cord to heat.
- Unplug the AC power cord from the electrical outlet before cleaning or moving the system, or when you do not intend to use the system for an extended period of time. When disconnecting, grasp the AC power cord by the plug and pull straight out of the electrical outlet. Never pull by the cord and do not pull out at an angle.
  Do not connect the AC power cord to a voltage transformer or inverter. Connecting the AC power cord to a voltage transformer for
- overseas travel or an inverter for use in an automobile may cause heat to build up in the system and may cause burns or a

### Never disassemble or modify the system or accessories

Use the  $\mathsf{PS4}^{\mathsf{IM}}$  system and accessories according to the instructions in the product documentation. No authorization for the analysis or modification of the system or accessories, or the analysis and use of its circuit configurations, is provided. Unauthorized modification of the system or accessories will void your warranty. There are no user serviceable components inside the PS4<sup>™</sup> system (the supplied hard disk may be removed but not disassembled or modified). Additionally, there is a risk of exposure to laser radiation as well as to electrical shock.

### Network

• A broadband connection is required to access the Internet. Note that You are responsible for Internet service fees. For details, refer to the

information provided in your service contract or contact you

 Do not use a cord for a standard residential telephone line or cables of types other than those mentioned here. Using the wrong type of cord or cable can cause more electrical current than necessary to flow through the LAN port, which may lead to heat build-up, fire or malfunction

### Wireless networking feature

 The frequencies used by the wireless networking feature of this product are the 2.4 GHz (WLAN, Bluetooth<sub>®</sub>)/5 GHz (WLAN) ranges. The 2.4 GHz range of radio waves is shared by various devices. This product has been designed to minimize the effect of other devices using the same range. However, in some cases, interference from other devices may reduce the connection speed, shorten the signal range, or cause the connection to be terminated unexpectedly.

When using the PS4<sup>™</sup> system's scan function to select a wireless LAN access point, access points that are not intended for public use may be displayed. Only connect to an access point that you are

on the disc. Should this occur, the system may not operate properly. In this case, remove the disc and turn off and unplug the system. Do not

pries, disconnect the AC power cord from the electrical outlet

put the disc back in until the moisture evaporates from the system

(this may take several hours). If the system still does not operate properly, contact Customer Service Hotline.

For safety reasons, before cleaning the system or connected

### Moisture condensation

authorized to use.

Cleaning

Permanent hearing loss may occur if the headset or headphones are used at high volume. Set the volume to a safe level. Over time, increasingly loud audio may start to sound normal but can actually be damaging your hearing. If you experience ringing or any discomfort in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the sooner your hearing could be affected. To protect your hearing: If the system or disc is brought directly from a cold location to a warm - Limit the amount of time you use the headset or headphones at one, moisture may condense either on the lens inside the system or

- Avoid raising the volume to block out noisy surroundings Lower the volume if you can't hear people speaking near you • Do not use the headset or headphones if they cause discomfort to your skin. If the headset or headphones cause discomfort to your
- skin, discontinue use immediately. If symptoms do not subside even after discontinuing use, seek medical attention. When using the headset or headphones in particularly dry air shock on your ears. This is a result of static electricity accumulated in the body, and is not a malfunction of your headset or

# About the USB device

If "An unknown USB device has been connected" is displayed

on-screen, the reason may be one of the following

from deteriorating or becoming discolored.

Wipe with a soft, dry cloth.

Exterior surfaces (plastic cover of system and wireless controller)

Follow the instructions below to help prevent the product exterior

 Do not use solvents or other chemicals. Do not wipe with a nically-treated cleaning cloth

# Vents

When dust accumulates in the system vents, remove the dust with a low-powered vacuum cleaner.

### Connectors Do not use when the connectors of the system or the AC power cord

are not clean. If used when dirty, the flow of electrical current may be obstructed. Remove the dirt with a dry cloth. Headset or headphones

If the connector on the headset or headphones becomes dirty, you may experience noise or interruptions in sound. Wipe the connectors with a dry, soft cloth to keep in clean condition

# Discs

Note on compatibility Some media may have region or territorial restrictions and may not work with your system. See media packaging for details.

Fingerprints, dust, dirt or scratches on the disc can distort the picture or reduce sound quality. Please note the following Do not touch the disc surface when handling a disc · Do not stick paper or tape onto discs and do not write on discs.

### Storage

- Do not expose discs to high temperatures, high humidity or direct sunlight When discs will not be used for an extended period of time, store them in their cases. Stacking uncased discs or storing them at an
- angle can cause them to warp.

### **Cleaning method**

3 Reinstall the system softwar

Replacement hard disk drives

Interface format Serial ATA \*2

2 Parallel ATA is not supported.

system.

▲ Caution

drive.

Notice

the system.

physical impact.

hard disk drive

- Clean discs with a soft cloth, lightly wiping from the center outwards. • Do not use solvents, record cleaners, anti-static
- spray or other chemicals as these can damage

- Replacing the hard disk drive Replace the hard disk drive by performing the following steps.
- 1 Back up your data. 2 Replace the hard disk drive.

2.5 inch (internal type)

For safety reasons, be sure to turn off and unplug the system before attempting to remove the hard disk drive.

Remove the hard disk drive in a location out of the reach of small children, to help prevent them from accidentally swallowing screws and other small parts.

The inside of the system is hot directly after use. Allow time for the system to cool down before starting to remove the hard disk

Be careful not to pinch your fingers between the parts or injure your hands or fingers on the corners of the parts.

Be sure to reattach the HDD bay cover before turning the PS4™ system on. If the cover is not in place, heat may build up inside

The hard disk drive is a sensitive piece of equipment and should

Do not throw or drop the system or hard disk drive, or

be handled with care at all times. To help prevent loss or corruption of software or data, or damage to the hard disk drive, carefully follow the precautions listed below:

otherwise expose either device to strong vibrations or strong

Do not allow liquid or small particles to get into the system o

Proper operation is not guaranteed for all models.

4 Restore data that has been backed up.

16T

# Service Hotline

system

You can use the following type of hard disk drive with the  $\mathsf{PS4}^{\mathrm{IM}}$ 

- ▲ Caution
- such as the screws.
- ontroller casing.

# Notice

- Do not touch the connectors or insert foreign objects into the
- Do not place the system or hard disk drive close to magnetic elds such as those produced by magnets or loudspeakers. Also, do not place devices that may be sensitive to magnetic forces (such as a wrist watch or a credit card) near the hard
- disk drive. Do not put heavy objects on the hard disk drive.
- Store in a cool, dry location. To attach or remove screws, use an appropriate crosshead
- crewdriver. If the size does not match, the groove on the screw's lead may be damaged.
- You should where possible make periodic back-ups of data stored on the hard disk drive as a precaution against possibl loss or corruption. If for any reason software or data loss or corruption occurs or the hard disk drive must be formatted during authorized service, it may not be possible to restore or repair the software or data. Note that Sony Interactive
- Entertainment Inc. and its subsidiaries and affiliates will not be liable for any loss or corruption of data, files or software. Do not turn off the PS4<sup>™</sup> system or remove the storage media
- luring the installation of the system software. Cancelling installation may result in damage to the system.
- During the installation of the system software, the power button on the system and the PS button on the controller are not active.

### Backing up data

You can copy data that is stored on the PS4<sup>™</sup> system to a USB storage device. For details on how to back up data and the types of data that you can back up, refer to the User's Guide (+-> "Further information").

### Replacing the hard disk drive

- On the function screen, select (<sup>1</sup>) (Power) > [Power Options] > [Turn Off PS4] to turn off the PS4<sup>™</sup> system. The power indicator turns off.
- 2 Unplug the AC power cord, and then disconnect the other cables from the system.
- For safety reasons, remove the plug for AC power cord from the electrical outlet, and then disconnect the other cables.
- 3 Turn the PS4<sup>™</sup> system upside down, and then on the system rear, hook your finger on the HDD bay cover and pull in the direction of the arrow to remove the cover.

### 4 Remove the hard disk drive.

emove the screw





Remove the screws (4 places) from the mounting bracket. o not remove the rubber inserts from the screw holes.



move the mounting bracket from the hard disk drive. Insert the replacement hard disk drive into the mounting bracket, and then secure it using the screws (4 places)

### Do not overtighten the screws 8 Insert the hard disk drive into the PS4<sup>™</sup> system, and then

secure it using the screw. Push on the hard disk portion to fully insert it into the PS4™



**9** Reattach the HDD bay cover.

If you lose the HDD bay cover, screws, mounting bracket, or any other parts, contact Customer Service Hotline (... "Further information").

### Installing the system software

After the hard disk drive has been replaced, the system software must be reinstalled. Using a computer, save a system software update file for reinstallation to a USB storage device. For details on how to perform the reinstallation, refer to the update site (•• Further information").

 You must reinstall system software that is either the same version or a later version of the system software that was in use before replacing the hard disk drive. If the appropriate update data for your system is not available on the website, contact Customer Service Hotline.

If you cannot connect to the Internet from a computer, contact Customer

### Copying data to the PS4<sup>™</sup> system

You can copy backed up data from a USB storage device to the PS4<sup>11</sup> system. For details on how to back up data and the types of data that you can back up, refer to the User's Guide.

### When disposing of the wireless controller

The lithium-ion battery of the wireless controller is recyclable. When disposing of the wireless controller, remove the battery and follow local regulations regarding disposing of batteries.

### • Remove the battery in a location out of the reach of small children to help prevent accidental swallowing of small parts

Be careful not to hurt your nails or fingers when removing the

- For safety reasons, attach tape or a seal on the metal part of the battery before disposing.
- Other than when disposing of the wireless controller, never remov the screws and never remove the battery from the wireless

### 1 Disconnect the USB cable from the wireless controller

2 Using a crosshead screwdriver, remove the screws (4 places).



3 With the front of the controller pointing up, press in the direction of the arrows to open the cover



**4** With the rear of the controller pointing up, remove the cover. **5** After disconnecting the connector, remove the battery.



Connector

Hard disk drive

Optical drive

(read-only)

# ecifications

Design and specifications are subject to change without notice Depending on the software version in use, the system may operate differently than described in this manual.

### PlayStation<sub>®</sub>4 system

Single-chip custom processor CPU: x86-64 AMD 'Jaguar", 8 cores GPU: 4.20 TFLOPS, AMD Radeon™ based graphics engine
GDDR5 8 GB
Internal, 1 TB <sup>*1 *2</sup>
BD 6× CAV DVD 8× CAV

Wavelength: 640-675 nm Power: Max. 1 mW Wavelength: 765-805 nm Power: Max. 1 mW SuperSpeed USB (USB 3.1 Gen1) port × 3 nput/output AUX port Ethernet (10BASE-T, 100BASE-TX, 1000BASE-T IEEE 802.11 a/b/g/n/ac uetooth<sub>®</sub> 4.0 (LE) HDMI<sup>™</sup> OUT port AV output DIGITAL OUT (OPTICAL) port DUALSHOCK<sub>®</sub>4 wireless cor AC 220-240 V, 50 / 60 Hz 310 W aximum rated power 
 External dimensions
 Approx. 295 × 55 × 327 mm

 (excluding projecting parts)
 (width × height × depth)
 Approx. 3.2 kg Operating temperature 5 °C to 35 °C HDMI cable USB cable Nain supplied items ono headset (with muting feature) AC power core

Type: Semiconductor, contin

Power: Max. 1 mW

Wavelength: 395-415 nm

\*1 Hard disk capacity calculated using base 10 mathematics (1 TB = 1,000,000,000 bytes).

- \*2 A portion of the hard disk capacity is reserved for use in connection with system administration, maintenance, and additional options. This may occur upon installation of system software or other software. As a result, the availability of hard disk capacity may vary depending on the system, system software version, or available options, and is not otherwise available for your use.
- \*3 CDs cannot be played. \*4 Functionality of all connected devices is not guaranteed
- \*5 Use the supplied HDMI cable.
- \*6 Varies depending on the country or region

### DUALSHOCK<sub>®</sub>4 wireless controlle

Input power rating	DC 5 V, 800 mA
Battery type	Built-in lithium-ion battery
Voltage	DC 3.65 V
Battery capacity	1,000 mAh
Operating temperature	5 °C to 35 °C
Mass	Approx, 210 g

### Playable discs

	PlayStation <sub>®</sub> 4 format BD-ROM <sup>*2</sup>
Blu-ray Disc™ (BD)'1	BD-ROM
Blu-ray Disc (BD)	BD-R
	BD-RE <sup>*3</sup>
	DVD-ROM
DVD"	DVD+R/RW
DVD ·	DVD-R/RW
	AVCHD

\*1 The first time you play a disc, you must enable the disc playback feature

- over the Internet.
- \*2 PlayStations format software, PlayStations2 format software, and PlayStations3 format software cannot be played from a disc. \*3 Playback of BD-RE ver. 1.0 discs is not supported.

### Region codes

Depending on the disc, a region code that is based on the geographic region where the disc is distributed may be assigned. The PS4" em can play discs marked with the following region codes



- DVD discs that have not been finalized cannot be played. Do not use the following discs. If you do, the system may be
- damaged - 8 cm discs
- Non-circular discs, such as discs in the shape of a card, star, or - Discs that are cracked or deformed, or discs that have been
- repaired. • A DualDisc features one side that conforms to the DVD standard
- and another side with audio only. The audio-only side cannot be played on the PS4<sup>™</sup> system. • When playing discs with content that was copied fraudulently,
- abnormal sounds may be produced or the content may not play correctly.
- For continuous playback of copyright-protected BDs, the encryption key for AACS (Advanced Access Content System) may need to be renewed. The encryption key is automatically renewed if the PS4™ ystem is connected to the Internet.
- Some discs may not be playable due to scratches, dust, the quality of recording, or the characteristics of the recording device In rare instances, BD and DVD may not operate properly when
- played on the PS4<sup>™</sup> system. This is primarily due to variations in the nanufacturing process or encoding of the software.

### System software

By updating the system software of the PS4<sup>™</sup> system, you can enjoy onal features, improved usability, and enhanced security. Always update to the latest version.

- If you cannot update over the Internet, you can use a game disc or USB storage device instead. For details, visit the update site (•• Further information").
- The system software included within this product is subject to a limited license from Sonv Interactive E Refer to doc.dl.playstation.net/doc/ps4-eula/ for further details.

### HARDWARE WARRANTY

For warranty terms and conditions of respective regions, please refer to the "Support" page of the official website asia.playstation.com, or call our Customer Service Hotline (••▶ "Further information").

### Further information

User's Guide Select 🚘 (Settings) > 🌮 (User's Guide/Helpful Info) > 🎲 (User's Guide) rom the function screen. This document contains explan is of how to use each function, how to perform settings, and other operations. You can also view the User's Guide from a computer or other device. manuals.playstation.net/document/en/ps4/

Update site The update site of the Official Website (see below) provides the latest information about system software updates, including how to update the system software.

The PlayStation® product support site of the Official Website (see below) provides the latest questions and answers about your product. Official Website

asia.playstation.com

Customer Service Hotline

Mon to Sun 9:00-20:00 Hong Kong 852-2341-2356 Singapore 800-8523-663

# СТ

為避免觸電,請勿打開外殼擅自分解。維修僅能由 專業的維修人員進行。

若使用耳機組或耳機時音量調整過高,可能會導致永久失聰。請將音量

生檢查聽覺。音量越高,會越快對聽覺造成影響。為保護您的聽覺

● 
日機組或互機對皮膚造成不適時請停止使用。若互機組或互機對您的皮

• 當在空氣乾燥的氣候下使用耳機組或耳機時, 耳朵可能會感到輕微並短

如果連接一組USB外接裝置,畫面卻顯示「已連接一台不明的 USB裝置。」

請勿處理已損壞或電解液外洩的鋰電池。內建電池電解液外洩時,立即 停止使用本產品並致電客戶服務熱線以取得協助。若電解液接觸到皮

相当时间的运行通过。 若您在提供年無線控制器時忽然開始感覺疲勞,或手臂、手腕感覺不舒服 或疼痛時,請立即停止使用主機。如果不良症狀持續存在,請立即就

→ 無線控制器的震動機能可能會令傷勢惡化。當您手臂、手腕的骨骼、關 節或肌肉有任何不適或受傷時,請勿使用震動機能。如果您有任何不適

請注意,部分軟件會將震動機能預設為啟用。若要停用震動機能,請在

· 調定》中的和中部機動機能引致(為MA) 台叉行用展動機能;調定 機能畫面選擇 ▲ (設定) > [周邊機器] > [控制器],並在[啟用 震動機能]的方格取消打勾。 • 使用無線控制器的動態感測(Motion Sensor)機能時,請注意以下事

使用經由USB連接線與PS4™主機相連的控制器時,請確認周圍有充足

的空間並且該連接線不會撞擊到人體或物品。同時並確實避免該連接

- 其他系列的主機如PlayStation®、PlayStation®2及PlayStation®3專用的

ACIDA73131上版ALF1432410118~「14354101182人F14354101183号 配件或周邊裝置,如類比控制器(DUALSHOCKs)、對比控制器 (DUALSHOCKs2)及DUALSHOCKs3無線控制器不支援PS4™主機。

控制器的光條閃爍時,請勿注視光條。若因光線的刺激而感到身體任何

· 建建添在温度介於10℃~30℃的最填下替電池充電。在其他温度的環 填下充電可能會減低充電的效率。

電池的壽命有限。電池續航力(使用時間)會因重複使用的次數與時間 而不斷減少。電池的壽命會因保管方法、使用情形、環境以及其他要素

• 長時間不使用無線控制器時,建議您仍應每年至少完全充電一次,以維

請先進行所有其他連接後再將主機的交流電源線插入電源插座。在連接至主機前,請確認電視機或其他連接線並未插入插座。

請定期榜查交流電源線,以確保操作安全。若有損壞,請立即停止使 用,並連絡客戶服務熱線(↔▶「更多資訊」)。

• 請勿使用隨附之交流電源線以外的其他電源線。且切勿改造該電源線。

• 請避免誤踩或掐擠交流電源線,尤其是插頭、轉接用的插座與電源線等

局力還次塵或異物堆積於交流電源線的連接端周圍。在連接或插入交流 電源線前,需確認是否有灰塵或異物堆積於交流電源線插頭、連接線末 端之歸子卻位、電源插座或主機背面的交流電源輸入端子。插頭或端子

• 請勿將交流電源線放置在靠近加熱設備的場所,且切勿讓電源線暴露於

當您準備開始清潔、移動,或打算長時間不使用主機時,請自電源插座 中拔出交流電源線。在拔下交流電源線時,請捉住交流電源線插頭筆直 地從電源插座拔出。切勿拉扯連接線或強制朝特定方向拔取。

• 請勿將交流電源線插入變壓器或反相器。將交流電源線插入海外旅行者

使用PS4™主機與附屬品時務必請遵守產品基本文書記載的指示說明。嚴

禁擅自分解或改造主機、附屬品,並禁止分解和使用其電路結構,增自分 解主機或附屬品將喪失所有保證權益。切勿擅自維修PS4™主機內部的零

• 連接網路雲先連接窗頻網際網路( 互聯網 ) 。請注音不支援撥號連接。

您需支付與網路連線時的必要費用。詳細請參閱服務契約之提供內容或

• 請勿使用一般家庭的標準電話線或本說明書內所述類型以外的連接線。

時分及Chribtex是UK非常和認識的是的是因素是的意志通過LAN連 使用類型錯誤之連接線連接,可能會造成超過需要量的電流通過LAN連 接埠,並可能會導致過熱、火災或是故障。

•本產品的無線網路功能所使用之頻率為2.4 GHz (無線LAN, Bluetooth®)/

◆使用PS4™主機的掃描功能選擇無線LAN基地台(access point)時,可能 會顯示非提供公眾使用的基地台。您僅能使用經授權能合法使用的基地

若把主機或光碟從寒冷的地方直接搬放到溫暖的場所,機內的透鏡或光碟

可能會凝結水氣。此種現象可能會導致主機無法正常運作。這時,請把当

碟取出,關閉電源,並拔掉主機電源插頭。在水氣尚未蒸發前,切勿再次 插入光碟(水氣蒸發可能需要數小時)。如果主機仍無法恢復正常的話,

為了安全著想,請在開始清潔主機或已連接之附屬品前,先自電源插座中

(可依需要移除標準配備的硬碟機但禁止分解或改裝),否則可能會有

使用的變壓器或汽車專用的反相器,可能會導致交流電轉換器發熱,並

請勿阻塞任何通風孔。為維持良好的通風,請遵循以下各項規則:

• 將主機放置在距離牆壁至少10 cm以上的場所。

• 切勿放置在有長纖維的地毯或毛毯上。

請勿用濕手觸摸交流電源線的端子。

自主機延伸出來的組件更需注意。

變髒時,請使用乾淨軟布擦拭。

切勿分解、改造主機或附屬品

遭受雷射輻射或觸電的危險。

聯絡您的網路服務商。

導致連線忽然意外中止。

請聯絡客戶服務熱線,以取得必要協助。

外彀表面(主機和無線控制器的翅膠蓋)

• 切勿使用殺蟲劑或其他具揮發性的物質。

清薄循以下使用說明,以免產品外殼變形或變色,

• 切勿在產品外殼上長時間放置任何橡膠或乙烯基材質。

當主機通風孔堆積灰塵時,使用低功率的吸塵器去除灰塵。

象。此時請以乾淨軟布擦拭,以維持清潔乾淨

• 切勿使用溶劑或其他化學藥劑。切勿使用經化學處理的擦布擦拭。

主機或交流電源線的端子部位出現髒污時請勿繼續使用。未去除髒污前若

耳機組或耳機的連接端子出現污痕,可能會造成噪音或聲音出現中斷現

繼續使用,可能會阻塞電流通過。此時應使用乾淨軟布去除灰塵。

無線網路功能

結露現象

清潔

通風孔

端子

耳機組或耳機

拔出交流電源線

• 使用軟布輕柔擦拭。

• 請勿在電線上放置重物。

高溫中。

網路

造成灼傷或故障

• 切勿放置在狹窄或擁擠的空間中。

• 切勿讓灰塵堆積在通風孔中。

項。控制器若撞擊到人體或物品,可能會導致意外、傷害或損傷。

· 使用控制器時,請確實握住並確認它不會從您手中滑出。

<u>这受傷</u>,請勿使用無線控制器遊玩含有震動機能的遊戲,否則請先停用

、衣物或眼睛,請立即用乾淨清水沖洗該部位。如果引起發炎或疼

留止工業和成功素候上区的社场超载并成的。并不可能自然的社场显达 暂的刺痛。此情形並非耳機組或耳機發生故障,而是人體釋放體內累積 的靜電所造成。

膚造成不適時,請立即停止使用。停止使用後,若狀況仍舊沒有改善

- 使用耳機組或耳機時請盡量避免將音量調整過高。

- 若無法聽清楚身邊的人的說話聲,請調低音量。

- 避免調高音量來阻隔身邊的噪音。

請立即就醫

關於USB裝置

的訊息,可能為下列原因

該裝置僅兼容特定軟件。

• 您連接之USB裝置不支援本主機。

• 可能連接了過多的USB Hub(集線器)。

使用DUALSHOCK®4無線控制器\*

痛,請洽詢您的醫生。電解液可能會導致失明。

• 避免長時間使田無線控制器。請每30分鐘休息一次。

- 使用前,請檢查您周圍是否有足夠的空間。

線忽然被從PS4™主機強硬拔除。

部位不適或疼痛,請立即停止使用。

而出現差異。

持電池性能

請勿用布覆蓋。

使用交流電源線

通風孔

\* 此注意事項亦適用於其他控制器。

日达市马城市战斗机场时目里间走过间。一场后曾考达小人大楼。前所有自重 割整至安全水平。持续散毙。一段時間後,即使是告望不断增大的嘈吵着 音,聽起來可能會與一般無異,但實際上卻可能會損害聽覺。若您感到 耳鳴或出現口齒不肯的情況,請立即停止使用耳機組或可接機。並完詞醫

### 注意 非依指定方式而進行的操作、調整以及執行動作可 能會導致放射線洩漏。

使用本產品時若搭配光纖,可能會增加眼睛受損的 6險。



依據IFC60825-1:2007 2014,本家電用品隸屬CLASS 1 LASER產品分類

### 光敏感/癲癇/突發性疾病

有極少數人,當看到某些亮光或閃光時,可能會有癲癇發作或暫時性眩暈 的情形。如果這些人看到電視螢幕上的某些圖案或背景,或者在遊玩遊戲 ,可能會引發癲癇或暫時性眩暈。某些從未有過癲癇的人 些情況下被引發出來。如果您或您的家人有癲癇狀況或任何突發性疾病 在遊玩遊戲前請先洽詢醫生。

如果您或您的孩子有以下任何一種健康問題或症狀,**請立即停止**使用,必 須先洽詢醫生,才能繼續遊玩遊戲 頭暈,

- 視覺障礙 • 眼睛或肌肉抽動
- 意識不清
- 精神恍惚 • 突發性疾病,或者
- 不自主的動作或肌肉抽動。 必須經醫生許可才能繼續遊玩遊戲。

- 減少發病可能性的遊戲使用和操作注意事項 • 請在光線良好的地方使用,並且盡量與螢幕保持遠距離。
- 避免使用大螢幕電視機。請使用尺寸最小的電視螢幕。
- 避免長時間使用PlayStation®4主機。每玩1小時請休息15分鐘 • 避免在您疲勞或需要睡眠時遊玩。

### 3D影像

有些人在使用3D電視機觀看3D影像或遊玩3D立體遊戲時,可能會感到不 舒服(例如眼睛疲勞、噁心等)。若您感到不舒服,請立即停止使用您的 arma(可如此時期效分,每00分)。有总局的目前加於,前立位许严正使用总由 電視機,直至不舒服的症狀消退。 Sony Interactive Entertainment建議所有使用者在觀看3D影像或遊玩3D立 體遊戲時,應該定時休息。休息的時間和次數因人而異,請休息足夠時 間。直至不舒服的症狀消退。如果症狀持續存在,請立即就醫。 幼童(特別是6歲以下者)的視力仍在發育階段。Sony Interactiv Entertainment建議在讓幼童觀看3D影像或遊玩3D立體遊戲前,應先洽詢

Enter talminenteetaattaaku)重制自力的医外发组织力以上超过最份制一般为行品到 醫生(例如小兒科醫生或眼科醫生)。成人偏監督幼童以確保化們得受力 述建議。使用PS4™主機時若同時使用任何支援3D的裝置,請先閱讀該裝 置的使用說明書。 無線電波

- 無線電波可能會影響電子設備或醫療裝置(例如心律調整器),且可能會 導致這些設備或裝置故障或損壞
- 若您有使用心律調整器或其他醫療裝置,請在使用無線網路機能 he與無線LAN)前,先詢問您的主治醫生或您身上之醫療裝置 的製造廠商。 • 請勿在下列場所使用無線網路功能
- 禁止使用無線網路的場所,如:醫院。在醫院中使用主機時,請遵守 - 接近火災警報器、自動門或其他類型之自動化設備的場所,

使用本產品前,請先詳細閱讀本指南,並妥善保存,以備將來參考之用。

本產品是在充分重視安全性能的情況下設計的。但如果使用不當,任何電器產品都有可能引起火災觸電或人身傷害的潛在危險。為確保安全操作,

· 如果裝置出現動作不正常,或者發出異常聲音或氣味,或因過熱而無法 觸碰時,請立即停止使用,並從電源插座中拔掉交流電源線插頭及所有 的其他連接線。

關於產品安全與支援的詳細資訊,請瀏覽官方網站(••▶ 「更多資訊」)。

• 請勿放置在封閉的櫃子或其他可能積熱的場所中使用。否則可能會導致

若您在操作無線控制器時忽然開始感覺疲勞,或手聲、手腕感覺不舒服 或疼痛時,請立即停止使用主機。如果不良症狀持續存在,請立即就

- 當眼睛、耳朵、手臂、手腕等,身體一部分感覺不舒服或疼痛時

請將本產品放在兒童拿不到的地方保管。兒童可能會誤吞小零件或用連接線纏繞自己,而造成身體損傷或導致意外發生、機器故障。

與主機連接的任何電視機或配件,必須為操作正常且沒有任何損壞。若 與主機連接的電視機或配件有任何問題或損壞,可能會損壞電視機或配件 件、或主機本身。所有的電子產品,若與任何有問題或損壞的配件連 使,或所連接之電源插頭未有正確連接線路,皆可能會導致出現火花,

• 請勿將主機或附屬品暴露在灰塵、煙霧或蒸氣中。此外,請勿將主機放

請勿以垂直或水平以外的方式放置主機。以垂直方式放置主機時,請使

• 請小心搬運主機。若您未確實持拿主機,可能會導致主機掉落並有造成

請在電源指示燈熄滅後再拔掉交流電源線的插頭。若在電源指示燈亮燈 或閃爍時拔除電源線,可能會造成資料毀損、消失或故障。

和內林時次於時間時間。 電源指示燈亭燈或閉樂時,請勿移動主機或改變主機位置,否則可能會 造成資料毀損、消失或故障。

• 請勿讓身體長時間接觸使用中的主機或從主機通風孔排出的氣體。長時

主機與電漿電視(Plasma TV)或投影\*電視機連接時,切勿讓畫面長時 間顯示同一個靜態影像,否則可能會導致模糊影像的永久殘留。

• 建議家長監督兒童的線上活動,以確保網際網路(互聯網)使用時的安

• 請勿於主機上站立或放置物品,且請勿在主機上堆放其他裝置。

• 請勿將主機和與其連接的附屬品放置在地板或可能絆倒人的地方。

• 請勿將主機或附屬品放在高溫、濕氣極重或受日光直射的地方

• 請勿將主機或附屬品放在傾斜、不平穩或易受震動的地方。

置在有很多灰塵或香煙煙霧的場所。在內部零件(例如透鏡)中堆積的 灰塵或香煙煙霧,可能會導致主機故障。

請將主機與周邊機器及細小零件放置在幼童拿不到的地方保管。

連接HDMI連接線前,請務必先從電源插座拔掉交流電源線。

• 請在光線良好的地方使用,並與電視螢幕保持一段安全距離。

家長及監護人應詳讀本指南並確保兒童遵守安全注意事項

• 遵守所有警告條文、注意事項及使用說明。

主機過熱並引發火災、人身傷害或故障。

• 避免長時間使用PS4™主機和無線控制器。

頭昏眼花,噁心、疲勞或類似暈船感覺

• 請勿在雷雨天氣中,觸摸主機、連接線或附屬品。

• 請勿讓液體、小零件或其他異物掉入主機或附屬品中。

切勿在靠近水的場所使用主機或附屬品。

• 請勿觸摸主機或附屬品的端子部分。

用本主機型號專用的直立架(另售)

•請勿在硬碟機保存或載入資料時關閉主機的電源。

指壞戓人身傷害的潛在性危險。

間接觸這些可能導致低溫灼傷。

定期檢查交流電源線是否有損壞。

### 使用前須知事項

關於安全

請導循以下各項規則

使用和保養

繼續使用。

相容性的注意事項 部分媒體可能因地區或區域的限制而無法使用您的主機啟動。詳細請參閱 媒體上的包裝

光碟上的指印、灰塵、污垢或刮痕可能使圖像失真,或降低聲音品質。請 遵守以下事項。 • 請勿觸摸光碟光亮的讀寫面

• 請勿在光碟上粘貼紙張或膠帶,以及在光碟上寫字。 保管

• 請勿將光碟放在高溫、濕氣極重或受日光直射的地方。 • 若長時間不使用光碟,請將它們保管在光碟盒中。堆放未收納的光碟或 傾斜放置保管可能造成光碟彎曲。

167

### 清潔方式

• 用軟布清潔光碟,從中間往外輕輕地擦拭。 • 請勿使用溶劑、唱片清潔劑、防靜電噴霧劑或其他 化學藥劑,否則可能會損壞光碟。

請依照以下步驟更換硬碟機。 1 替資料進行備份。

- 更換硬碟機 重新安裝系統軟件
- 4 將已備份的資料還原(復原)

# 更換硬碟機

您可在PS4™主機內使用以下類型的硬碟機。 5 英吋(內接式

### 介面規格 Serial ATA \*1 不保證所有機型皆能正常操作

\*2 不支援Parallel ATA

### ⚠ 注意

- 為您安全著想, 請務必在嘗試移除硬碟機前關閉電源並拔掉主機插 請在兒童無法靠近的場所移除硬碟機,以避免誤吞螺絲等小零件。
- 使用後的主機會從內部直接發熱。請在開始移除硬碟機前先暫時放 置,以令主機冷卻。
- 請注意不要被零件的隙縫夾傷手指,或被零件的銳角傷到手或手指。
- 啟動PS4™主機電源前請先確認HDD護蓋是否已確實重新插入。假若 未插入護蓋,可能會導致主機內部的溫度持續升高。

### 重要

- 硬碟機是架構非常靈敏的裝置,進行上述類似處理時務必隨時小心注意。為避免遊戲或資料遺失、毀損,並避免損傷硬碟機,請務必遵守以下所列的注意事項。 請勿投擲或掉落主機或硬碟機,或使其受到強烈的震動或強烈的 外力撞擊。
- 請勿讓液體或小零件掉入主機或硬碟機中。
- 請勿觸摸或將異物插入連接線的連接端子部分。
- 請勿於硬碟機上堆放沉重物品。 請放置在涼爽且乾燥的場所保管。
- 要安裝或拔取螺絲時,請使用尺寸適切正確的十字頭螺絲起子。尺寸 若不符,可能會損壞螺絲頭的溝槽。
- 建議您定期替儲存於硬碟機內的資料預留備份,以預防資料遺失或毀損。無論理由為何,遊戲或資料一旦遺失或毀損,或者硬碟機於維修時必須格式化,即已無法復原或修理。Sony Interactive
- 3須格式化,即已無法復原或修理。Sony Interactive ertainment Inc.與其子公司、關係企業對於資料、檔案或遊戲的遺 、毀損,概不承擔任何責任
- 請勿於更新中關閉P54™主機的電源或拔除儲存媒體。更新若遭到中 斷,可能會導致主機故障。
- 主機前面的電源按鈕與無線控制器的PS按鈕可能會於更新途中失效

### 備份資料

可將PS4™主機內的資料複製至USB儲存裝置。關於如何備份資料與可備份 的資料類型,請參閱用戶指南(••▶「更多資訊」

### 更換硬碟機

- 在機能畫面選擇()(電源)>[電源選項]>[關閉PS4的電源]
   關閉PS4™主機的電源。 電源指示燈會熄滅
- 2 拔掉交流電源線之後,拔除插在主機上的其他連接線。 為了安全著想,請先將交流電源線從電源插座中拔出,再拔除其他連
- 接線。 3 將PS4™主機倒轉,在主機背面將手指扣在HDD護蓋上,並朝箭頭方

向拉動以取下護蓋



4 移除硬碟機。 ①取出螺絲

②將硬碟機與安裝托架一起拉出。

5 從安裝托架上取出螺絲(共4顆)。





- 7 將更換用的硬碟機放進安裝托架,並旋緊螺絲(共4顆)。
- 注意螺絲切勿轉動過緊。 8 將硬碟機插入PS4™主機,並使用螺絲固定。
- 推動硬碟部分,以完全插入PS4™主機內。



9 重新插上HDD護蓋

若您遺失了HDD護蓋、螺絲或安裝托架等必要零件,請致電客戶服務熱線 ●「更多資訊」

# 安裝系統軟件

更换硬碟機後,需重新安裝系統軟件。使用個人電腦,將系統軟件的更新 檔案(重新安裝用)保存至USB儲存裝置。詳細操作方法請瀏覽系統更新 網站(••▶「更多資訊」)

• 您無法重新安裝比更換硬碟機之前更舊的更新資料版本。若於網站無法下載適 切版本的更新資料,請致電客戶服務熱線 • 若您沒有能與網際網路連線的電腦,請致電客戶服務熱線。

# 將資料複製至PS4™主機

可將USB儲存裝置內的備份資料複製至PS4™主機。關於如何備份資料與可 備份的資料類型,請參閱用戶指南。

# 丟棄無線控制

- 無線控制器的鋰電池是可回收的。要丟棄無線控制器時,請先將電池取 ,並遵循當地法規,正確處理廢棄電池。 <u> 注</u>意 • 請在兒童無法靠近的場所移除電池,以避免誤吞螺絲等小零件。
- •拆卸控制器的外殻時,請小心不要弄傷您的指甲或手指。 · 為了安全著想, 請在丟棄前先於電池的金屬零件部位貼上膠帶或貼
- 重要 除進備丟棄無線控制器外,絕對不要從無線控制器中取出螺絲或電池。
- 1 拔掉無線控制器上的USB連接線。
- 2 使用十字頭螺絲起子,取出螺絲(共4顆)



**3** 將控制器的正面朝上<sup>,</sup>再往箭頭的方向將蓋子推開。



**4** 將控制器的背面朝上, 取下蓋子。



# 本公司保留在沒有事先通知情況下,變更設計或規格之權利。 本說明書中介紹的主機操作方式可能因使用之系統軟件版本先後,而與實

# PlayStation®4主機

央處理器	單晶片專用處理器 CPU:x86-64 AMD"Jaguar", 8核心 GPU:4.20 TFLOPS, AMD Radeon™ based圖像引擎
隐體	GDDR5 8 GB
ē碟機	內藏 1 TB*1*2
5學驅動 唯讀 )	BD 6 × CAV DVD 8 × CAV
"射	類型:半導體,連續性 BD波長: 395-415 nm 能量:最大1 mW DD/波長: 640-675 nm 能量:最大1 mW CD波長: 756-805 nm 能量:最大1 mW
入 / 輸出*4	SuperSpeed USB(USB 3.1 Gen1 )連接埠( × 3 ) AUX連接埠
路	乙太網路(10BASE-T,100BASE-TX,1000BASE-T) IEEE 802.11 a/b/g/n/ac Bluetoothゅ 4.0(LE)
音輸出	HDMI™輸出連接埠 <sup>rs</sup> DIGITAL OUT (OPTICAL)連接埠
制器	DUALSHOCK®4無線控制器
源	AC 220-240 V, 50/60 Hz*6
大額定電力	310 W
·觀尺寸 不包括最大突出部分 )	約295 × 55 × 327 mm (寛 × 高 × 深)
量	約3.2 kg
峰作溫度	5 °C ~ 35 °C
要隨附品	HDMI連接線 USB連接線 單聲道耳機組(搭載靜音機能) 交流電源線
在神上一四六日五体长。	

- \*1 硬碟之可用容量乃依據1TB等於1兆位元組的計算式而計算。
  \*2 硬碟的部分容量會用於系統管理、維修及其他追加選項等。此為安裝系統軟件或其他軟件時,為確保能啟動系統而預留的分割區。因此,實際可利用之 硬碟容量會因系統軟件的版本或其他追加選項等而異。
- \*3 無法播放CD。
- 4 不保證所有已連接裝置可正常使用 \*5 請使用隨附的HDMI連接線。
- 可能因國家、地區而異。

# DUALSHOCK®4無線控制器

カ晋型鋰離子電池
DC 3.65 V
000 mAh
5 ℃ ~ 35 ℃
ሳ210 g
5

# 可播放的光碟

	PlayStation®4規格BD-ROM <sup>*2</sup>
Blu−ray Disc™ (BD)*1	BD-ROM
SIU-TAY DISC (DD)	BD-R
	BD-RE <sup>*3</sup>
	DVD-ROM
DVD*1	DVD+R/RW
JVD -	DVD-R/RW
	AVCHD

- 1 初次播放光碟時,您必須先透過網際網路啟用光碟播放機能。 \*2 無法播放光碟版的PlayStation®規格軟件、PlayStation®2規格軟件和
- tion®3規格軟件
- \*3 不支援播放BD-RE ver. 1.0光碟。

光碟之區域碼皆隨光碟之可能銷售區域而制定。PS4™主機能播放標有以

CS

注意

损的危险。

专业的维修人员进行。

能会导致放射线泄露。

光敏感/癫痫/突发性疾病

在游玩游戏前请先咨询医生。

头晕,

视觉障碍

• 意识不清,

精神恍惚

3D影像

备的使用说明书。

的制造厂商。

其规定。

关于安全

请遵守以下各项规则

的其他连接结

使用和保养

\*\*\*\*

无线电波

• 眼睛或肌肉抽动

• 突发性疾病,或者

• 不自主地动作或肌肉抽动

必须经医生许可才能继续游玩游戏。

• 避免在您疲劳或需要睡眠时游玩。

直至不舒服的症状消退。

导致这些设备或装置故障或损坏。

• 请勿在下列场所使用无线网络功能:

使用前须知事项

• 遵守所有警告条文, 注意事项及使用说明。

• 避免长时间使用PS4™主机和无线控制器。

- 头昏眼花、恶心、疲劳或类似晕船感觉

• 请勿在雷雨天气里触摸主机、连接线或附属品。 • 切勿在靠近水的场所使用主机或附属品。

• 请勿触摸主机或附属品的接口部分。

用本主机型号专用的直立架(另售)

间接触这些可能导致低温灼伤。

1 CD屏幕类型除外

• 请勿在硬盘保存或载入数据时关闭主机的电源。

请勿让液体、小零件或其他异物掉入主机或附属品中。

• 请将本产品放在儿童拿不到

• 定期检查交流电源线是否有损坏

减少发病可能性的游戏使用和操作注意事项

• 请在光线良好的地方使用,并且尽量与屏幕保持远距离。

• 避免长时间使用PlayStation。4主机。每玩1小时请休息15分钟。

有些人在使用3D电视观看3D影像或游玩3D立体游戏时,可能会感到不舒

体游戏时 应该完时休息。休息的时间和次数因人而导 请休息足够时

医生(例如小儿科医生或服科医生)。家长远看它儿童,确保他们遵守以上建议。使用PS4™主机时若同时使用任何对应3D的设备,请先阅读该设

无线电波可能会影响电子设备或医疗装置(例如心脏起搏器),且可能会

→ 若您有使用小脏起褥器或其他医疗装置,请在使用无线网络功能 (Bluetooth。与无线LAN)前,先咨询您的主治医生或您身上的医疗装置

- 禁止使用无线网络的场所,如:医院。在医院中使用主机时,请遵守

· 接近火灾报警器、自动门或其他类型的自动化设备的场所。

使用本产品前,请先仔细阅读本指南,并妥善保存,以备将来参考之用。 家长及监护人应详读本指南并确保儿童遵守安全注意事项。

本产品是在充分重视安全性能的情况下设计的。但如果使用不当,任何电器产品都有可能引起火灾触电或人身伤害的潜在危险。为确保安全操作,

如果设备出现动作不正常,或者发出异常声音或气味,或因过热而无法 触碰时,请立即停止使用,并从电源插座中拔除交流电源线插头及所有

•关于产品安全与支持的详细信息,请浏览官方网站(••▶"更多信息")。

请勿放置在封闭的柜子或其他可能积热的场所中使用。否则可能会导致 主机过热并引发火灾、人身伤害或故障。

土的运动厂力资本及、人名匈日本地传送时形时,立即关闭主机电源并 暂时中止使用。待主机确实冷却后,才将主机搬移至通风良好的场所并 经达4年

若您在操作无线控制器时突然开始感觉疲劳,或手臂、手腕感觉不舒服 或疼痛时,请立即停止使用主机。如果不良症状持续存在,请立即就

若您有遭遇以下健康问题,请立即停止使用主机。如果不良症状持续存在,请立即就医。

- 当眼睛、耳朵、手臂、手腕等,身体一部分感觉不舒服或疼痛时

• 请将主机与周边设备及细小零件放置在儿童拿不到的地方保管。

接线缠绕自己,而造成身体伤害或导致意外发生,设备故障。

与主机连接的任何电视或配件,必须是操作正常且没有任何损坏。
 主机连接的电视或配件有任何问题或损坏,可能会损坏电视或配件
 主机本身。所有的电子产品,若与任何有问题或损坏的配件连接,

连接的电源插头未正确连接线路、皆可能会导致出现火花、引起火灾。

15.004亿土0.004亿土0.004亿土0.004 请勿将主机或附属品暴露在灰尘、烟雾或蒸汽中。此外,请勿将主机放 置在有很多灰尘或香烟烟雾的场所。在内部零件(例如透镜)中堆积的 灰尘或香烟烟雾,可能会导致主机故障。

• 请勿以垂直或水平以外的方式放置主机。以垂直方式放置主机时,请使

请小心搬运主机。若您未拿好主机,可能会导致主机掉落并有造成损坏 或人身伤害的潜在性危险。

请在电源指示灯熄灭后再拔掉交流电源线的插头。若在电源指示灯亮灯 或闪烁时拔除电源线,可能会造成数据毁损、丢失或故障。

电源指示灯亮灯或闪烁时,请勿移动主机或改变主机位置,否则可能会造成数据毁损、丢失或故障。

• 请勿让身体长时间接触使用中的主机或从主机通风孔排出的气体。长时

1 主机与等离子电视或投影\*电视连接时,切勿让画面长时间显示同一个静态影像,否则可能会导致模糊影像的永久残留。

• 请勿在主机上站立或放置物品,且请勿在主机上堆放其他装置。

• 请勿将主机和与其连接的附属品放置在地板或可能绊倒他人的地方

• 建议家长监控儿童的在线活动,以确保互联网使用时的安全可靠。

• 请勿将主机或附属品放在高温、湿气极重或受日光直射的地方。

• 请勿将主机或附属品放在倾斜、不平稳或易受震动的地方。

• 连接HDMI连接线前,请务必先从电源插座拔除交流电源线。

• 请在光线良好的地方使用。并与电视屏墓保持一段安全距离。

间,直至不舒服的症状消退。如果症状持续存在,请立即就医。 幼童(特别是6岁以下的)的视力仍在发育阶段。Sony Interactive

(例如眼睛疲劳、恶心等)。若您感到不舒服,请立即停止使用您的电

teractive Entertainment建议所有使用者在观看3D影像或游玩3D立

rtainment建议在让幼童观看3D影像或游玩3D立体游戏前,应先咨询

• 避免使用大屏幕电视。请使用尺寸最小的电视屏幕。

须先咨询医生、才能继续游玩游戏

CLASS 1 LASER PRODUCT

LASER KLASSE 1 PRODUKT

为避免触电,请勿打开外壳擅自分解。维修仅能由

非依指定方式而进行的操作,调整以及执行动作可

使用本产品时若搭载光学工具,可能会增加眼睛受

根据IEC60825-1: 2007.2014,本家电用品隶属CLASS 1 LASER 产品分类。

有极少数人,当看到某些亮光或闪光时,可能会有癫痫发作或暂时性晕眩

的情形。如果这些人看到电视屏幕上的某些图案或背景,或者在游玩游戏

山间水。如本这些大量到全地桥带上的来兰国来或有深,或有比如地和 时,可能会引发癫痫或暂时性晕眩。某些从未有过癫痫的人,也可能在这 些情况下被引发出来。如果您或您的家人有癫痫症状或任何突发性疾病,

如果您或您的孩子有以下任何一种健康问题或症状,**请立即停止**使用,必

下區域碼的光碟。	
光碟	區碼
Blu-ray Disc (BD)	
DVD	
PlayStation®4規格BD-ROM	

# 重要

- 無法播放未經最終化處理之DVD光碟。 請勿使用以下光碟,使用此類光碟可能會導致主機故障。 - 8 cm光碟
  - 卡片形、星形或心形等不規則形狀的光碟。
- 已損壞、重新塑形或曾經修復的光碟。
- DualDisc(雙層光碟)是結合DVD面與音樂面,有兩層記錄層的光 碟。PS4™主機無法播放光碟的音樂面。 • 播放非法複製的光碟內容時,可能會出現異常聲音或無法正確播放內
- 若想繼續享受內建著作權保護之BD光碟的播放機能,可能需要更新
- AACS(Advanced Access Content System)加密鍵。與網際網路連線時 會自動更新加密鍵。 某些光碟可能因刮傷、灰塵、錄製品質不佳或受錄製裝置之特性影響
- 而無法正確播放 BD、DVD光碟可能會罕見地發生無法在PS4™主機上正確操作的現象。 這主要是起因於軟件在製造過程或編碼時發生的差異

### 關於系統軟件

用戶指南

系統更新網站

支援

官方網站

客戶服務熱線

一至週日 9:00-20:

雪港 852−2341−2356

新加坡 800-8523-663

- PS4™主機的系統軟件可诱過更新,追加各式各樣的機能、改善操作性或
- 強化安全性。請經常將系統軟件更新至最新版本。
- 若您無法透過網際網路進行更新,可另外改用遊戲光碟及USB儲存裝置 來更新。詳細內容請瀏覽系統更新網站(••▶「更多資訊」)。 • 本產品中內建的系統軟件乃受Sony Interactive Entertainment Inc.限制授
- 權。詳情請閱覽以下網站:doc.dl.playstation.net/doc/ps4-eula

您亦可透過電腦或其他裝置閱覽用戶指南。

有關各地區的保用條款及細則,請瀏覽官方網站asia.playstation.com的 支援」頁面,或致電客戶服務熱線(••▶「更多資訊」)。

從機能畫面選擇 🚘 (設定)> 🐢 (用戶指南 / 便利資訊)> 🎲 (用戶指南 ) 此文件載有如何使用每個機能、執行設定和其他操作的說明。

官方網站(見下文)的系統更新網頁提供系統軟件更新的最新資訊,包括更新系 統軟件的方法。

官方網站(見下文)的PlayStation®產品支援網頁,提供產品的最新常見問題和解

### 若使用耳机组或耳机时音量调整过高,可能会导致永久失聪。请将音量 调整至安全水平。持续聆听一段时间后,即使是音量不断增大的嘈杂声 音。听起来可能会为一般无异,但实际上却可能会损害听觉,若您感到 耳鸣或出现口齿不清的情况,请立即停止使用耳机组或耳机,并洽询医 生检查听力。音量越高、会越快对听力造成影响。为保护您的听力 ·使用耳机组或耳机时请尽量避免将音量调整过高。 ·避免调高音量来阻隔身边的噪音。

· 若无法听清楚身边人的说话声,请调低音量。

 耳机组或耳机对皮肤造成不适时请停止使用。若耳机组或耳机对您的质量。 4111-224-607-1月之即停止使用。停止使用后,若状况仍旧没有改善, 肤造成不适时,请立即停止使用。停止使用后,若状况仍旧没有改善, 请立即就医。

当在空气干燥的气候下使用耳机组或耳机时,耳朵可能会感到轻微并短 暂的刺痛。此情形并非耳机组或耳机发生故障,而是人体释放体内累积

### 如果连接一组USB外接设备,画面却显示"已连接一台不明的USB设备。"的 信息、可能为下列原因 • 您连接的USB设备与本主机不兼容。 • 该设备仅兼容特定软件

• 可能连接了过多的USB集线器

关于USB设备

用震动功能。

切能画面选 的方框取消

而出现差异,

请勿用布覆盖。

造成灼伤或故障。

网络

无线网络功能

结露现象

清洁

通风孔

拔出交流电源线

通风孔

### 使用DUALSHOCK®4无线控制器\*

• 请勿处理已损坏或电解液外泄的锂电池。内置电池泄露电解液时,请立 即停止使用本产品并致电客户服务热线以取得必要协助。若电解液接触 到皮肤、衣物或眼睛,请立即用干净清水冲洗该部位。如果引起发炎或 疼痛,请洽询医生。电解液可能会导致失明。 若您在操作无线控制器时忽然开始感觉疲劳或手臂、手腕感觉不舒服或 疼痛时,请立即停止使用主机。如果不良症状持续存在,请立即就医。 无线控制器的震动功能可能会令伤势恶化。当您手臂、手腕的骨骼、关 节或肌肉有任何不适或受伤时,请勿使用震动功能。如果您有任何不适 或受伤,请勿使用无线控制器游玩包含有震动功能的游戏,否则请先停

•避免长时间使用无线控制器。请每30分钟休息一次。 请注意,部分软件会将震动功能预设为启用。若要停用震动功能,请在功能画面选择 ▲ (设定)>[周边设备]>[控制器],并在[启用震动功能]

使用无线控制器的动态感测(Motion Sensor)功能时,请注意以下事项。控制器若撞击到人体或物品,可能会导致意外、伤害或损伤。

- ·使用前,请检查您周围是否有足够的空间。 ·使用控制器时,请确实握住并确认它不会从您手中滑出。 ·使用通过USB连接线与PS4™主机相连的控制器时,请确认周围有充足
- 其他系列的主机如PlayStatione、PlayStatione3及PlayStatione33 配件或周边设备,如模拟控制器(DUALSHOCK®)、模拟控制器
- 前1140年20日前,11月1日日日 (DUALSHOCK=2)及DUALSHOCK=3无线控制器不对应PS4™主机。 控制器的光条闪烁时,请勿注视光条。若因光线的刺激而感到身体任何
- 部位不适或疼痛,请立即停止使用。 · 建议您在温度介于10℃~30℃的环境下为电池充电。在其他温度的环境下充电可能会降低充电的效率。
- 电池的寿命有限。电池续航力(使用时间)会因重复使用的次数与时间 而不断减少。电池的寿命会因保管方法、使用情形、环境以及其他要素

• 长时间不使用无线控制器时,建议您仍应每年至少完全充电一次,以维 此注意事项也适用于其他控制器。

请勿阻塞任何通风孔。为维持良好的通风,请遵循以下各项规则: • 将主机放置在距离墙壁至少10 cm以上的场所。 • 切勿放置在有长纤维的地毯和毛毯上。

• 切勿放置在狭窄或拥挤的空间中 • 切勿让灰尘堆积在通风孔中。

### 使用交流电源线

- 请先进行所有其他连接后再将主机的交流电源线插入电源插座。在连接 至主机前,请确认电视或其他连接线并未插入插座。 请定期检查交流电源线,以确保操作安全。若有损坏,请立即停止使 用,并连络包装盒上记载的客户服务热线(••▶ "更多信息")。
- 请勿使用随附的交流电源线以外的电源线。且切勿改造该电源线。 • 请勿用湿手触摸交流电源线的插头。
- 请避免误踩或掐挤交流电源线,尤其是插头、转接用的插座与电源线等 从主机延伸出来的组件更需注意。 • 请勿在电线上放置重物。
- 请勿让大火尘或异物堆积于交流电源线的接口周围。在连接或插入交流电源线前,需确认是否有灰尘或异物堆积于交流电源线插头、连接线末端的接口部位、电源插座或主机背面的交流电源输入接口。插头或接口变 脏时, 请使用干净软布擦拭。
- 请勿将交流电源线放置在靠近加热设备的场所,且切勿让电源线暴露于 同一下。 当您准备开始清洁、移动,或打算长时间不使用主机时,请从电源插座 中拔出交流电源线。在拔下交流电源线时,请抓住交流电源线的插头笔 直地将插头从电源插座拔出。切勿拉扯连接线或强制朝特定方向拔取。 请勿将交流电源线插入变压器或反相器。将交流电源线插入海外旅行者 使用的变压器或汽车专用的反相器,可能会导致交流电转接器发热,并

# 切勿分解、改造主机及附属品

使用PS4™主机与附属品时务必请遵守产品基本文件记载的指示说明。严 禁擅自分解或改造主机、附属品,并禁止分解和使用其电路结构。擅自分 解主机或附属品将丧失所有保障权益。切勿擅自维修PS4™主机内部的零 (可依需要移除标准配备的硬盘驱动器但禁止分解或改装),否则可能 会有遭受镭射辐射或触电的危险。

• 连接网络需先连接宽带互联网。请注意不支持拨号连接。

- 您需支付与网络连线时的必要费用。详细请参阅服务合约中提供服务的 内容或联络您的网络供应商。
- •本产品的无线网络功能所使用的频率为2.4 GHz (无线LAN, Bluetooth®)/ 5 GHz (无线LAN)的范围。2.4 GHz无线电波范围万属各种设备共用分享。 本产品的设计已将来自使用相同范围的其他设备的影响降到最低。然而,来自其他设备的干扰仍可能会降低连线速度、缩短信号范围,或导 致连线忽然意外中断。
- •使用PS4™主机的扫描功能选择无线LAN接入点时,可能会显示非公用的 **4 移除硬盘驱动器**。 接入点。您仅能使用经授权可合法使用的接入点。 ①取出螺丝。

若把主机或光碟从寒冷的地方直接搬到温暖的场所,机内的透镜或光碟可 能会凝结水气。此类现象可能会导致主机无法正常运作。这时,请把光碟取出,关闭电源,并拔掉主机电源插头。在水气尚未蒸发前,请勿再次插入光碟(水汽蒸发可能会要数小时)。如果主机仍无法恢复正常的话, 请联系客户服务热线,寻求必要帮助。

为了安全着想,请在开始清洁主机或已连接其附属品前,先从电源插座中

# 外壳表面(主机和无线控制器塑料壳)

请遵循以下使用说明,以免产品外壳变形或变色。 • 使用软布轻柔擦拭

• 切勿使用杀虫剂或其他具挥发性的物质。 • 切勿在产品外壳上长时间放置任何橡胶或乙烯基材质。 • 切勿使用溶剂或其他化学药剂。切勿使用经化学处理的擦布擦拭。

当主机通风孔堆积灰尘时,使用低功率的吸尘器去除灰尘。

主机或交流电源线的接口部位出现脏污时请勿继续使用。未去除污痕前若 继续使用,可能会阻塞电流通过。此时应使用干净软布去除污痕。

耳机组及耳机的接口有污痕,可能会造成噪音或断音。请用干净软布擦 拭,并保持清洁干净

部分媒体可能因地区或区域的限制而无法使用您的主机启动。详细请参阅

光碟上的指印、灰尘、污垢或刮痕可能使图像失真,或降低声音品质。请

• 若长时间不使用光碟,请将它们保管在光碟盒内。堆放未收纳的光碟或

• 请勿在光碟上粘贴纸张或胶带,以及在光碟上写字。

• 请勿将光碟放在高温、湿气极重或受日光直射的地方。

媒体上的包装

皇守以下事项

• 请勿触摸光碟光亮的读取面。

倾斜放置保管可能造成光碟弯曲。

化学药剂,否则可能会损坏光碟。

**手换硬盘驱动**:

1 为数据进行备份

**更换硬盘驱动器** 

重新安装系统软

更换硬盘驱动器

接口规格

▲ 注意

重要

烈的外力撞击。

驱动器附近

请依照以下步骤更换硬盘驱动器。

4 将已备份的数据还原(复原)。

\*1 不保证所有机型皆能正常操作

2 不兼容Parallel ATA。

您可在PS4™主机内使用以下类型的硬盘驱动器。

Serial ATA

2.5 英寸 (内置式

为您的安全着想,请务必在尝试移除硬盘驱动器前关闭电源并拔掉主 机插头。

·请在儿童无法靠近的场所移除硬盘驱动器,以避免误吞螺丝等小零

• 使用后的主机会从内部直接发热。请在开始移除硬盘驱动器前先暂时

局动PS4™主机电源前请先确认HDD槽盖是否已确实重新插入。假若 未插入槽盖,可能会导致主机内部的温度持续升高。

硬盘驱动器是架构非常灵敏的设备,进行上述类似处理时务必随时小 心注意。为避免游戏或数据遗失、毁损,且避免损伤硬盘驱动器,请 务必遵守以下所列的注意事项。

·请勿让液体或小零件掉入主机或硬盘驱动器中。

请勿触摸或将异物插入连接线的连接接口部分。

·请勿在硬盘驱动器上堆放沉重物品

请放置在凉爽且干燥的场所保管。

的数据类型,请参阅用户指南(••▶"更多信息")

2 拔掉交流电源线后,拔除插在主机上的其他连接线。

断,可能会导致主机故障。

备份数据

更换硬盘驱动器

S4™主机的电源

电源指示灯会熄灭

向拉动以取下槽盖。

①取出螺丝。

②将硬盘驱动器与安装支架一起拉出。

5 从安装支架上取出螺丝(共4颗)。

请勿取出螺丝孔内的橡胶。

6 从安装支架中取出硬盘驱动器。

注意螺丝切勿转动过紧。

7 将更换用的硬盘驱动器放入安装支架,并旋紧螺丝(共4颗)。

请勿投掷或掉落主机或硬盘驱动器,或使其受到强烈的震动或强

请勿将主机或硬盘驱动器放置在磁铁或喇叭(扬声器)产生的磁 场附近。且勿将对磁力敏感的装置(手表或磁卡等)放置在硬盘

安装或拔取螺丝时,请使用尺寸适合、正确的十字螺丝刀。尺寸若 符,可能会损坏螺丝头的沟槽。

itertainment Inc.与其子公司、关联公司对于数据、文件或游戏的遗 、毁损,概不承担任何责任。

请勿在升级中关闭PS4™主机的电源或拔除存储设备。升级若遭到中

可将PS4™主机内的数据复制至USB存储设备。关于如何备份数据与可备份

在功能画面选择 🕛 (电源)>[电源选项]>[关闭PS4的电源],关闭

为了安全着想,请先将交流电源线从电源插座中拔出,再拔除其他连

3 将PS4™主机倒转,在主机背面将手指扣在HDD槽盖上,并朝箭头方

主机前面的电源键与无线控制器的PS键可能会在升级途中失效

建议您定期为存储于硬盘驱动器内的数据预留备份,以预防数据遗失 或毁损。无论理由为何,游戏或数据一旦遗失或毁损,或者硬盘驱动 器在维修时必须格式化,即已无法复原或修理。Sony Interactive

• 请注意不要被零件的隙缝夹伤手指,或被零件的锐角伤到手或手指

• 用软布清洁光碟,从中间往外轻轻地擦拭。

• 请勿使用溶剂、唱片清洁剂、防静电喷雾剂或其他

兼容性的注意事项

光碟

保养

保管

清洁方式

耳机组及耳机

# 9 重新插上HDD槽盖。

(••▶ "更多信息")

8 将硬盘驱动器插入PS4™主机,并使用螺丝固定。

推动硬盘部分,使其完全插入PS4™ 主机内。

### 安装系统软件

更换硬盘驱动器后,需重新安装系统软件。使用电脑,将系统软件的升级 文件(重新安装用)保存至USB存储设备。详细操作方法请浏览系统升级 网站(••▶"更多信息")。

 您无法重新安装比更换硬盘驱动器之前更旧的升级数据版本。若在网站无法下载合适版本的升级数据,请致电客户服务热线。 • 若您没有能与网络连接的电脑,请致电客户服务热线,

### 将数据复制至PS4™主机

可将USB存储设备内的备份数据复制至PS4™主机。关于如何备份数据与可 备份的数据类型,请参阅用户指南。

# 丢弃无线控制器时

无线控制器的锂电池是可回收的。要丢弃无线控制器时,请先将电池取 出,并遵循当地法规,正确处理废弃电池。

### ▲ 注意

•请在儿童无法靠近的场所移除电池,以避免误吞螺丝等小零件。 拆卸控制器的外壳时,请小心不要弄伤您的指甲或手指。

为了安全着想,请在丢弃前先在电池的金属零件部位贴上胶带或贴

重要

除准备丢弃无线控制器外,绝对不要从无线控制器中取出螺丝或电池

# 1 拔掉无线控制器上的USB连接线



3 将控制器正面朝上,按箭头方向推开盖子。







本公司保留在没有事先通知的情况下,变更设计或规格的权利。本说明书中介绍的主机操作方法可能因使用的系统软件版本先后,与实际不同。

### PlayStation®4主机

片专用处理器 x86-64 AMD "Jaguar", 8核心 4.20 TFLOPS, AMD Radeon™ based图形引擎 R5 & GB 1 TB"' <sup>2</sup> × CAV & CAV & × CAV & × CAV & × CAV & × 2395-415 nm : 最大1 mW x625-645 nm : 最大1 mW x627: 765-805 nm : 最大1 mW r5peed USB (USB 3.1 Gen1) 端口(×3)
1 TB <sup>3 · 2</sup> * CAV * CAV * = CAV : 半导体,连续性 长: 395-415 nm : 最大1 mW 波长: 640-675 nm : 最大1 mW 长 <sup>2</sup> : 765-805 nm : 最大1 mW · :最大1 mW · :最大1 mW · :最大1 mW
* CAV 8 × CAV : 半导体,连续性 长: 395-415 nm : 最大1 mW 波长: 640-675 nm : 最大1 mW 长 <sup>2</sup> : 765-805 nm : 最大1 mW · :最大1 mW · :5pced US8 (USB 3.1 Gen1 ) 端口 ( × 3 )
8 × CAV : 半导体,连续性 长: 395-415 nm : 最大1 mW 波长: 640-675 nm : 最大1 mW 代 <sup>2</sup> : 765-805 nm : 最大1 mW rSpeed USB (USB 3.1 Gen1) 端口(×3)
代: 395-415 nm : 最大1 mW 波长: 640-675 nm : 最大1 mW 代 <sup>21:</sup> 765-805 nm : 最大1 mW rSpeed USB (USB 3.1 Gen1) 端口(×3)
端口
网络(10BASE-T, 100BASE-TX, 1000BASE-T) 802.11 a/b/g/n/ac tooth® 4.0(LE)
NI™输出端口⁵ 数字输出端口
LSHOCK®4无线控制器
20-240 V, 50/60 Hz*6
N
5 × 55 × 327 mm × 高 × 深)
2 kg
~ 35 °C
11连接线 车接线

1 硬盘可用内存是根据1 TB等于1万亿字节的计算式而计算。

- \*2 硬盘的部分容量会用于系统管理、维修及其他追加项目等。此为安装系统软 件或其他软件时,为确保能启动系统而预留的分区。因此,实际可利用的确
- 盘容量会因系统软件的版本或其他追加项目等而异。
- \*3 无法播放CD。 \*4 不保证所有已连接设备可正常使用。
- \*5 请使用随附的HDMI连接线。
- \*6 可能因国家、地区而异。

### DUALSHOCK<sub>®</sub>4无线控制器

额定电压/额定输入电流	DC 5 V, 800 mA
电池类型	内置型锂离子电池
电压	DC 3.65 V
电池容量	1000 mAh
操作温度	5 °C ~ 35 °C
重量	约 210 g

# 可播放的光碟

	PlayStation®4规格BD-ROM <sup>*2</sup>	
Dia	BD-ROM	
Blu−ray Disc™ (BD)*1	BD-R	
	BD-RE <sup>13</sup>	
	DVD-ROM	
DVD*1	DVD+R/RW	
DVD ·	DVD-R/RW	
	AVCHD	

- \*1 初次播放光碟时 您必须先通过互联网启用光碟播放功能 \*2 无法播放光碟版的PlayStation®规格软件、PlayStation®2规格软件和
- NavStation®3规格软件

\*3 不支持播放 BD-RE ver. 1.0光碟。

# 区域码

光碟的区域码皆根据光碟的可能销售区域而制定。PS4™主机能播放标有 以下区域码的光碟。

光碟	区域码
Blu-ray Disc (BD)	$\bigcirc$
DVD	
PlayStation®4规格BD-ROM	

- 无法播放未经最终化处理的DVD光碟。
- 请勿使用以下光碟,使用此类光碟可能会导致主机故障。 - 8 cm光碟
- 卡片形、星形或心形等不规则形状的光碟。 - 已损坏、重新塑形或曾经修复的光碟。
- DualDisc(双层光碟)是结合DVD面与音频面的双层记录层光碟。 PS4™主机无法播放光碟的音频面。 •播放非法复制的光碟内容时,可能会出现异常声音或无法正确播放内容
- 若要继续播放内含著作权保护内容的BD光碟,可能需要更新 AACS(Advanced Access Content System)密钥。与互联网连接时,会自 动更新密钥。
- 某些光碟可能因刮伤、灰尘、录制品质不佳或受录制设备的特性影响, 而无法正确播放。
- BD、DVD光碟可能会罕见地发生无法在PS4™主机上正确操作的现象。 这主要是因为软件在制造过程或编码时发生的差异。

### 关于系统软件

PS4™主机的系统软件可通过升级,追加各式各样的功能、改善操作性或 强化安全性。请经常将系统软件升级至最新版本。 14.103年116月1日、1942年11日、1942年11月3日、1942年11月3日、1942年11月、1942年11日、1942年11月、1942年11

本产品中内置的系统软件受Sony Interactive Entertainment Inc.限制授权。详情请阅览以下网站:doc.dl.playstation.net/doc/ps4-eula/

有关各地区的保修条款及细则,请浏览官方网站asia.playstation.com的"支 援"页面,或致电客户服务热线(••▶"更多信息")

从功能画面选择 🍰 ( 设定 ) > 🐶 ( 用户指南/有用信息 ) > 🎲 ( 用户指南 ) 此文件包含如何使用每个功能、执行设定和其他操作的说明。

官方网站(见下文)的系统升级页面提供系统软件升级的最新资讯,包括升级系

PlayStation®产品帮助的官方网站(见下文),提供产品的最新常见问题和解答。

", "PlayStation", "アーケーム" and "DUALSHOCK" are registered

trademarks or trademarks of Sony Interactive Entertainment Inc

AMD and Radeon are trademarks of Advanced Micro Devices, Inc.

"SONY" and ". are registered trademarks or trademarks of Sony

The Bluetooth ${\scriptstyle \$}$  word mark and logos are owned by the Bluetooth SIG Inc. and any use of such marks by Sony Interactive Entertainment Inc.

is under license. Other trademarks and trade names are those of their

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Manufactured under license from Dolby Laboratories. Dolby and the

For DTS patents, see http://patents.dts.com. Manufactured under

Java is a registered trademark of Oracle and/or its affiliates.

USB-IF SuperSpeed USB Trident logo is a registered trademark of USB

All other trademarks are the property of their respective owners

license from DTS Licensing Limited. DTS, DTS-HD, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS-HD Master Audio | 7.1 is a trademark

double-D symbol are trademarks of Dolby Laboratories

of DTS, Inc. © DTS, Inc. All Rights Reserved.

Java

POWERED

Sony Interactive

Entertainment

© 2018 Sony Interactive Entertainment Inc. Printed in China

SS←

"Blu-ray Disc™" and "Blu-ray™" are trademarks of the Blu-ray Disc

### 更多信息

系统升级网站

统软件的方法。

官方网站

asia.playstation.cor

周一至周日 9:00-20:00

香港 852-2341-2356

新加坡 800-8523-663

客户服务热线

Corporation

respective owners

edts-#D

您也可通过电脑或其他设备浏览用户指南

用户指南