

**DualSense™ Wireless Controller**

DualSense™ 無線控制器 / DualSense™ 无线控制器 /  
DualSense™ 무선 컨트롤러

Instruction Manual / 使用说明书 / 使用说明書 / 사용설명서

CFI-ZCT2G

5-070-236-11(1)

5-070-236-11(1)

EN

**Health and Safety**

Before using the product, carefully read this manual and any manuals for compatible hardware. Retain instructions for future use. Parents or guardians of children should read this manual for safe use.

This product has been designed with the highest concern for safety. However, any electrical device, if used improperly, has the potential for causing fire, electrical shock or personal injury. Observe all warnings, precautions and instructions.

Stop use and disconnect cables immediately if the product functions in an abnormal manner, produces unusual sounds or smells or becomes too hot to touch.

**WARNING  
RADIO WAVES**

Radio waves may affect electronic equipment or medical devices (for example, pacemakers), which may cause malfunctions and possible injuries.

• If you use a pacemaker or other medical device, consult your doctor or the manufacturer of your medical device before using the wireless networking feature (Bluetooth® and wireless LAN).

• Do not use the wireless networking feature in the following locations:

- Areas where wireless network use is prohibited, such as in hospitals. Abide by medical institution regulations when using the console on their premises.

- Areas near fire alarms, automatic doors and other types of automated equipment.

**MAGNETS AND MEDICAL DEVICES**

This product has magnets which may interfere with pacemakers, defibrillators and programmable shunt valves or other medical devices. Do not place this product close to such medical devices or persons who use such medical devices. Consult your doctor before using this product if you use such medical devices.

**VOLUME LEVEL**

Permanent hearing loss may occur if the headset or headphones are used at high volume.

Set the volume to a safe level. Over time, increasingly loud audio may start to sound normal but can actually be damaging your hearing. If you experience ringing or any discomfort in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the sooner your hearing could be affected. To protect your hearing:

- Limit the amount of time you use the headset or headphones at high volume.

- Avoid raising the volume to block out noisy surroundings.

- Lower the volume if you can't hear people speaking near you.

**LITHIUM-ION BATTERY**

The controller contains a lithium-ion rechargeable battery. Do not handle damaged or leaking lithium-ion batteries. If the built-in battery fluid leaks, stop using the product immediately and contact customer support. If the material gets into your eyes, do not rub. Immediately flush the eyes with clean water and seek medical attention. If the material comes into contact with the skin or clothes, immediately rinse the affected area with clean water and consult your doctor. Do not allow the battery to come into contact with fire or subject it to extreme temperatures such as direct sunlight, in a vehicle exposed to the sun or near a heat source.

Never attempt to open, crush, heat, or set fire to the controller or the battery. Do not leave the battery charging for a prolonged period of time when the controller is not in use.

**YOUNG CHILDREN INJURIES**

Keep the product out of the reach of young children. Young children may swallow small parts, may wrap the cables around themselves, which may inflict injury or cause an accident or a malfunction.

**NEVER DISASSEMBLE OR MODIFY THE PRODUCT OR ACCESSORIES UNLESS AUTHORIZED IN THIS MANUAL**

There is a risk of fire, electric shock or injury.

**⚠️ Precautions****Taking breaks**

• Avoid prolonged continuous use of this product. Generally we recommend that you take 15 minute breaks for every hour of play.

• Avoid playing when you are tired or need sleep.

**Compliance information**

Complies with  
IMDA Standards  
DBI02988

CT

**健康與安全**

使用本產品前，請先詳細閱讀本使用說明書和對應裝置的所有說明書，並妥善保存，以備將來使用。小孩的家長或監護人應閱讀本說明書以確保安全使用。

本產品是在充分重視安全性能的情況下設計的。但如果使用不當，任何電子產品都有可能引起火災、觸電或人身傷害的潜在危險。請遵守所有警告條文、注意事項及使用說明。

如果產品出現動作不正常、發出異常聲音或氣味、或因過熱而無法觸碰時，請立即停止使用，並放下所有連接線。

**⚠️ 警告****無線電波**

無線電波可能會影響電子設備或醫療裝置（例如心律調節器），且可能會導致這些設備或裝置故障或導致人身傷害。

• 若您有使用心律調整器或其他醫療裝置，請在使用無線網路機能（Bluetooth®與無線LAN）。

• 請勿在您的醫生或您身上之醫療裝置的製造廠商。

• 請勿在下列場所使用無線網路的功能：如：醫院。在醫院中使用主機時，請遵守其規定。

- 禁止使用無線網路的場所，如：醫院。在醫院中使用主機時，請遵守其規定。

- 接近火警報器、自動門或其他類型之自動化設備的場所。

**磁力與醫療器材**

本產品有磁力，可能會干擾心律調節器、心臟起搏器或可調式引導閥或其他醫療器材。請勿將本產品放在心臟起搏器或使用者使用此類醫療器材的使用者附近。如果您使用任何此類醫療器材，請在使用本產品前諮詢您的醫生。

**音量大小**

若使用耳機或耳機時音量調整過高，可能會導致永久失聽。請將音量調整至安全水平。持續聆聽一段時間後，即使是很小的嘈雜聲音，聽起來亦可能會與一般無異，但實際上卻可能會損害聽覺。若您感到耳鳴，耳鳴有任何不適或出現口齒不清的情況，請立即停止使用耳機或耳機，並及時就醫。音量過高，對聽覺造成的影響越快。為保護您的聽覺：

- 請限制高音量來降低周圍環境的噪音。

- 避免調高音量來阻隔周圍環境的噪音。

- 若無法聽清楚身邊人的說話聲，請調低音量。

**鋰離子電池**

控制器內含鋰離子充電電池。請勿處理已損壞或電解液外洩的鋰離子電池。若內置型電池的電解液外洩，請立即停止使用本產品並聯絡客戶服務中心以取得協助。若電解液物質不慎進入眼睛，請勿揉眼。

• 請立即用清水沖洗眼睛，並及時就醫。若電解液物質接觸到皮膚或衣物，請立即用清水沖洗該部位並諮詢醫生。請勿讓電池接觸火源，或是放置於高溫處，如受日光直射、曬置於日光下的車內或接近熱源的場所。切勿嘗試打開、撲滅、加熱或點燃控制器或電池。不使用控制器時，請勿讓電池長時間充電。

**關於幼童傷害**

請將本產品放在幼童拿不到的地方保管。幼童可能會誤吞細小零件、用連接線繞綁自己，而造成身體損傷或意外發生、機器故障。

**切勿分解、改造本產品或附屬品，除非本說明書另有指示說明**

可能會引起火災、觸電或受傷的危險。

**⚠️ 使用前須知事項****關於休息**

• 請避免長時間使用本產品。一般建議每遊玩一小時休息15分鐘。

• 避免在您疲勞或需要睡覺時遊玩。

• 如果您開始感覺疲勞，或在操作控制器時感到手或手臂不適或疼痛，請立即停止使用本產品。如果狀況持續存在，請立即就醫。

• 若您有遇到下列健康問題，請立即停止使用本產品。如果不良症狀持續存在，請立即就醫。

- 頭昏眼花、噁心、疲勞或類似動暈症的症狀。

- 身體部位如眼睛、耳朵、手或手臂感覺不適或疼痛。

**震動功能**

• 若將控制器置於平坦表面上，則遊玩過程中控制器的震動可能導致其摔落，進而導致人身傷害或故障。

• 若您患有任何可能受此震動功能影響的疾病或損傷，以及身體部位如手或手臂的骨骼、關節或肌肉有任何疾病或損傷，請勿使用震動功能或扳機效果功能。若要停用這些功能，請於PlayStation®主機的主畫面選擇 [設定] > [周邊機器]。

**靜電衝擊**

當在空氣特別乾燥的狀況下使用耳機組或耳機時，耳朵可能會感到輕微並短暫的刺痛。此情形並非耳機組或耳機本身故障，而是人體釋放體內累積的靜電所造成。您可以透過穿著不易產生靜電衝擊的材料製成的衣物來降低這種影響。

**動態感測器**

使用控制器的動態感測功能時，請確實注意以下數點。控制器若撞擊到人體或物品，可能會導致意外傷害或故障。

• 使用動態感測功能前，請確認您周圍有充足的運動空間。

• 請確實握住控制器，以防從您手中滑落並導致損壞或人身傷害。

- Stop using the product immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms while operating the controller. If the condition persists, consult a doctor.
- If you experience any of the following health problems, discontinue use of the product immediately. If symptoms persist, consult a doctor.
  - Dizziness, nausea, fatigue or symptoms similar to motion sickness
  - Discomfort or pain in a part of the body, such as eyes, ears, hands or arms

**Vibration function**

If the controller is sitting on a flat surface, the vibration of the controller during gameplay may cause it to fall, leading to injury or malfunction.

Do not use the vibration or trigger effect function if you have any ailment or injury to body parts such as the bones, joints, muscles of the hand or arm or that may be affected by the vibration function. To disable the features, select Settings ➔ Accessories from the home screen of the PlayStation®5 console.

**Static shock**

When using the headset or headphones in particularly dry air conditions, you may sometimes experience a small and quick 'static' shock on your ears. This is a result of static electricity accumulated in the body, and is not a malfunction of your headset or headphones. This effect could be reduced by wearing clothes made from materials that do not easily generate static shock.

**Motion sensor**

When using the motion sensor function of the controller be cautious of the following points. If the controller hits a person or object, it may cause accidental injury or damage.

- Before using the motion sensor function, make sure you have enough space to move around.
- Firmly grip the controller to prevent it from slipping out of your grasp and causing damage or injury.
- If using a controller that is connected to the PS5® console with a USB cable, make sure there is enough space for the cable so that the cable will not hit a person or object.

**Light bar**

Do not stare at the light bar on the controller when it is blinking. Stop using the controller immediately if you experience any discomfort or pain.

**Liquid, dust, smoke, steam and heat**

- Always ensure the product and its connectors are free of liquid, excess dust and small particles.
- Do not leave the product in the following areas during use, storage or transportation.
  - Areas exposed to smoke or steam
  - Areas with high humidity, dust or cigarette smoke
  - Areas near heating appliances, areas exposed to direct sunlight or areas that retain heat

**Set up and handling**

- Do not use the cables if they are damaged or modified.
- Do not place heavy items on the product or cables, throw or drop the product, or otherwise expose it to strong physical impact.
- Do not place the product on surfaces that are unstable, tilted or subject to vibration.
- Do not leave the product on the floor.
- Do not walk on the cables or pinch them, particularly near to the connectors.
- Do not pull or bend the cables with excessive force.
- Do not place the console and connected accessories on the floor or in a place where they may cause someone to trip or stumble.
- Do not touch the connectors or insert any foreign objects into them or the product.
- Unplug the cables if you want to clean or move the product or do not intend to use it for an extended period of time.
- Do not touch the product during an electrical storm.
- Do not expose the product, accessories or battery to high temperatures, high humidity, or direct sunlight during operation, transportation, and storage.

**Use and handling****Never disassemble or modify the product or accessories unless authorized in this manual**

Use the product and accessories according to the instructions in this manual. No authorization for the analysis or modification of the product, or the analysis and use of its circuit configurations, is provided.

**Handling the controller**

- Charge in an environment where the temperature range is between 10 °C and 30 °C. Charging may not be as effective when performed in other environments.
- The battery has a limited lifespan. Battery duration will gradually decrease with repeated usage and age. Battery life also varies depending on the storage method, usage state, environment, and other factors.

- When the controller is not used for an extended period of time, it is recommended that you fully charge it at least once a year in order to maintain battery functionality.
- The product and its parts are made from metal and plastic materials. When disposing of the product, follow local regulations for the proper disposal of such materials.

**Care and cleaning**

Follow the precautions below to help prevent the product exterior from deteriorating or discoloring.

- Do not apply volatile substances such as insecticide.
- Do not allow rubber or vinyl materials to be in prolonged contact with the product.
- Do not use thinner, benzine, or alcohol. Avoid using wipes, chemical cloths, and other products that contain such substances.

- 如果使用經由USB連接線與PS5®主機相連的控制器，請確認為連接線留出足夠的空間，以避免連接線撞擊到人體或物品。

**光條**

當控制器的光條閃爍時，請勿持續凝視光條。若感到任何不適或疼痛，請立即停止使用控制器。

**液體、灰塵、煙霧、蒸氣及高溫**

- 請始終確保本產品及其端子部位未沾染任何液體、大量灰塵及微細顆粒。

• 使用、保管或運輸過程中，請勿將本產品置於下列場所。

- 濕氣極重、多塵或者菸霧的場所

- 靠近加熱設備、受日光直射或持續保溫的場所

**設定與處理**

• 請勿使用已受損或經改造的連接線。

- 請勿在本產品或連接線上放置重物，亦勿投擲或掉落本產品，或者使其受到強烈的外力撞擊。
- 請勿將本產品放在不平穩、傾斜或易受震動的地方。

• 請勿踩踏或擠壓連接線，尤其是靠近端子的部位更需注意。

• 請勿過度用力拉扯或彎曲連接線。

• 請勿將控制器或任何附屬品放置在地板或可能絆倒的地方。

• 請勿觸摸端子或將任何異物插入端子或本產品中。

• 若您想要清潔、搬移或打算長時間不使用本產品時，請拔下連接線。

• 請勿在雷雨天氣中，觸摸本產品。

• 在操作及保管過程中，請勿將本產品、附屬品或電池放在高溫、濕氣極重或受日光直射的地方。

