


SONY®



PlayStation VR



Instruction Manual

使用說明書

사용설명서

EN

WARNING

Before using the product, carefully read this instruction manual and any manuals for compatible hardware and follow the warnings and instructions for set up. Retain this instruction manual for future reference.

- Do not use PlayStationVR if you are tired, dizzy, light-headed, nauseous, sick, under the influence of alcohol or drugs, or have an impaired sense of motion or balance. Consult a doctor before using PS VR if you suffer from a serious medical condition.
- Wearing the VR headset will restrict your view of your actual surroundings. The VR headset does not detect obstacles. Review surroundings and clear obstacles from an area larger than the Play Area before use. Please refer to the "About the Play Area" section in the Quick Start Guide for more information on how to set up the Play Area. Make sure you are not near any walls, stairs, furniture, or other obstacles that you may collide with or trip over.
- Take steps to prevent pets, persons, or other obstacles entering the play area during use.
- Remain in the center of the Play Area and do not walk around while wearing the VR headset. Remain seated whenever possible and avoid extreme or excessive movements of the head, limbs or body while wearing the VR headset. If an application requires you to stand while wearing the VR headset, ensure that you follow the application instructions carefully.
- Before beginning play, check that the VR headset is being used properly around your body or limbs, and check frequently during play.
- IMMEDIATELY DISCONTINUE USE and consult your doctor before resuming gameplay if you or your child experience any of the following health problems or symptoms: Dizziness, altered vision, eye or muscle twitches, loss of awareness, disorientation, seizures, or any involuntary movement or convulsion. RESUME GAMEPLAY ONLY ON APPROVAL OF YOUR DOCTOR.
- Some people may experience motion sickness, nausea, disorientation, blurred vision or other discomfort. If experienced, stop using immediately and remove the VR headset. Rest, and do not engage in any activities that require unimpaired vision, balance or coordination until after symptoms have completely disappeared.
- Do not use the product when you are tired or need sleep.
- Do not use the product in a location that may be subject to shaking or other unstable conditions.
- It may take some time to become accustomed to virtual reality experiences. During initial use, it is recommended that you use the product for short periods of time.
- Generally we recommend that you take 15 minute breaks for every hour of play. However, when viewing virtual reality content, the length and frequency of necessary breaks may vary from person to person - please take breaks that are long enough to allow any feelings of discomfort to subside.
- If you experience any discomfort after use, rest until the discomfort subsides.

Use by children
The VR headset is not for use by children under age 12.
Wearing the VR headset
<ul style="list-style-type: none">It is important that you place the VR headset on your head properly during use. <ul style="list-style-type: none">To see instructions on how to wear the headset, go to the PlayStation®4 system's function screen and then select (Settings) > [Devices] > [PlayStation VR]. <ul style="list-style-type: none">Do not overtighten the adjustment dial (→ "Part names"). You can wear the VR headset over your glasses but take care when adjusting the scope (→ "Part names"). Having your glasses touch the lens could result in damage to your glasses. VR headset lens or both. Do not push in or pull out the scope excessively.
<ul style="list-style-type: none">Regularly check the VR headset to ensure it is being worn properly.
VR headset screen
<ul style="list-style-type: none">Do not expose the lenses (→ "Part names") of the VR headset to direct sunlight or intense light. Doing so may damage the VR headset screen and cause a malfunction. Keep the VR headset's attachment sensor (→ "Part names") free from any obstacles. If the attachment sensor is blocked, the screen will not turn off automatically even if you remove the headset; an image appears on the screen for an extended period of time, it might cause a screen burn and a faint image might remain permanently on the screen. Black (dark) pixels and continuously lit pixels may appear in certain locations on the screen. The appearance of such spots is a normal occurrence associated with screens and is not a sign of a system malfunction. Screens are made using highly precise technology. However, a very small number of dark pixels or continuously lit pixels may exist and color irregularities or brightness irregularities may be visible on each screen.

Seizures induced by light stimulation (Photosensitive Epilepsy)
If you have an epileptic condition or have had seizures, consult your doctor prior to playing. Some individuals may experience eye soreness, altered vision, migraine, muscle twitching, convulsion, blackout, loss of awareness or disorientation when exposed to flashing or flickering lights or other light stimulation on a television screen or while playing video games. If you experience any of the above symptoms while playing, discontinue use immediately and consult your doctor.

Stop playing immediately when you experience the following symptoms
In addition to the above symptoms, whilst playing if you have a headache, dizziness, nausea, fatigue, similar symptoms to motion sickness, or if you feel a discomfort or pain in any body part such as eyes, ears, hands, arms, feet, discontinue use immediately. If the condition persists, seek medical attention.

Device software
The device software of the PS VR is licensed to you under the terms of a separate end user license agreement. For details, visit doc.ci.playstation.net/doc/psvr-eula/.

Precautions

Safety

- Do not damage the AC power cord and AC adaptor.
- For more information on product safety and support, visit our website (→ "Further information").

Use and handling

- Before connecting, check that the connectors are free of dust and small particles.
- Do not swing the VR headset or the AC adaptor around by their cables.
- Do not unplug the VR headset cable until the tracking lights (→ "Part names") are turned off. Removing or unplugging while the lights are on may cause a malfunction.
- Do not place objects on the product, throw or drop the product, or otherwise expose it to strong physical impact.
- Keep the product out of the reach of small children. Small children may pull out small parts, may pull on cables and cause the processor unit or VR headset to fall, or may wrap the cables around themselves, which may injure or cause an accident or a malfunction.
- Do not touch the AC power cord, AC adaptor or processor unit during an electrical storm.
- Do not allow liquid or small particles to get into the product (ports, vents, etc.). If this happens, stop use and disconnect it from the electrical outlet immediately.
- Do not expose the product to dust, smoke or steam. Dust or other matter can cause the plug of the AC power cord with wet hands.
- Do not avoid prolonged body contact with the processor unit, AC adaptor, or air from the vents when the product is turned on. Extended contact may cause low-temperature burns.*
- * Low-temperature burns are burns that occur when the skin is in contact with objects of relatively low temperatures (40 °C or more) for an extended period of time.
- Do not use the VR headset, stereo headphones, or stereo headset if they cause discomfort to your skin. If the headset or headphones cause discomfort to your skin, discontinue use immediately. If symptoms do not subside even after discontinuing use, seek medical attention.
- The product and its parts are made from metal and plastic materials. When disposing of the product, follow local regulations for the proper disposal of such materials.

Using PS VR

- Use with your PS4™ system and PlayStation Camera. PS VR brings you the excitement of virtual reality. You can interact with games more directly because the camera captures the position, angle, and movement of the VR headset.
- Be sure to always update your PS4™ system software and PS VR device software to the most recent version.
- Be sure to connect your VR headset to the supplied CUH-ZVR2 processor unit. The headset will not work if connected to a CUH-ZVR1 processor unit.

Your position while using the VR headset
Remain seated wherever possible. For applications with a standing mode, follow the application instructions carefully.

PS VR settings

To configure PS VR settings, go to the PS4™ system's function screen, and then select (Settings) > [Devices] > [PlayStation VR].

Hints

- These settings are available only when PS VR is connected to the PS4™ system.
- You can also configure some settings from the quick menu that appears when you press and hold the (PS) button on the controller.
- For more information about setting up your PS VR, refer to the user's guide for the PS4™ system. Select (Settings) > (User's Guide/Helpful Info) > (User's Guide) from the function screen.


Parental controls

The PS4™ system contains settings that parents or guardians can configure as necessary to restrict use of the product by children. To configure settings for each child, go to the PS4™ system's function screen, and then select (Settings) > [Parental Controls/Family Management].

Part names


VR headset

Front




- A)** Tracking lights (front)
Rear lights Blue: Powered on
Front and rear lights blue: VR mode
Front and rear lights off: Powered off
- B)** Scope-adjustment button
- C)** Front head support
- D)** Rear head support
- E)** HDMI connector
- F)** AUX connector
- G)** Scope

Rear



- A)** Headband
- B)** Attachment sensor
- C)** Lenses
- D)** Adjustment dial
- E)** Headband release button
- F)** Tracking lights (rear)
- G)** Earpiece holder

Bottom



- A)** Stereo headphone jack
- B)** Headphone attachment hole
- C)** (power) button
- D)** Light shield
- E)** Microphone
- F)** Tracking lights (front)
- G)** Volume + button
- H)** (Microphone mute) button
- I)** Volume - button

AC adaptor and AC power cord use

- Use an electricity supply that is easily accessible, so the AC power cord can be unplugged quickly if the need arises. Stop use, unplug the AC power cord from the electricity supply and disconnect any other cables immediately if the product functions in an abnormal manner, produces unusual sounds or smells or becomes too hot to touch.
- Unplug the AC power cord from the electricity supply when the status indicator on the processor unit is red. Unplugging the cord while the indicator is white or flashing red may cause a malfunction.
- Do not use an AC adaptor or AC power cord other than those supplied with the product. The supplied AC adaptor and AC power cord are designed exclusively for this product. They cannot be used with other products. In addition, other AC adaptors or AC power cords cannot be used with this product. Failure to follow these precautions may cause the product to overheat and may lead to fire or electric shock.
- Do not plug the AC power cord for the product into an electricity supply until you have connected the HDMI™ cables.
- Do not touch the plug of the AC power cord with wet hands.
- Do not use the AC adaptor when it is covered by a cloth, as it may overheat, causing fire or malfunction.
- Do not use the AC power cord from the electricity supply before (this may take several hours), if the product still does not operate properly, visit our website (→ "Further information").
- Do not connect the AC power cord to a voltage transformer or inverter.

Storage conditions

- Do not expose the product or accessories to high temperatures, high humidity or direct sunlight.
- Do not place the product or accessories on surfaces that are unstable, tilted or subject to vibration.


Processor unit

Front



- A)** Status indicator
White: Powered on
Red: Rest mode
- B)** AUX port
- C)** HDMI output port

Rear



- A)** HDMI TV port
- B)** HDMI PS4 port
- C)** (USB) port
- D)** DC IN 12V connector
- E)** Vent


Stereo headphones



- A)** Earpiece
- B)** Stereo headphone plug
- C)** Fastener

Changing the earpieces

The stereo headphones are supplied with M size earpieces attached. Replace the earpieces with the S or L size earpieces for a better fit. To remove, twist then pull the earpiece off the headphones.



Hint
Install the earpieces firmly to help prevent them from accidentally detaching during use.

Care and cleaning

Be sure to follow the instructions below to clean and maintain your product.

- For safety reasons, unplug the AC power cord from the electrical outlet and disconnect any other cables before cleaning.
- Do not use solvents or other chemicals to clean the exterior surfaces.
- Do not use a chemically-treated cleaning cloth to wipe the product.

Processor unit exterior, VR headset exterior, head supports, connectors

If they are dirty, wipe them with a soft, dry cloth.

Hint
If the connectors on the processor unit, AC power cord, or other parts are dirty, signals may not be sent or received properly. You may also experience noise or interruptions in the sound if the connectors on the headphones or headset are dirty.

Lenses


Wipe only with a soft, dry cloth made specifically for cleaning lenses. Do not use paper products such as paper towels, or tissues not specifically intended for lenses.

Hint

Prolonged contact with water or dust may damage the lenses and shorten their life.

Light shield

Remove the light shield from the VR headset and wash it with water. Dry it completely with a soft cloth before reattaching it to the headset. Reattach the light shield by matching the nuts on the shield to the 13 holes on the VR headset.



Vents
Remove dust build-up from the vents using a vacuum cleaner or similar product.

Earpieces

Remove the earpieces from the stereo headphones and wash them by hand with a mild detergent. Dry them completely with a soft cloth before reattaching them to the headphones.

For details on removing the earpieces, refer to "Changing the earpieces".

Specifications

Design and specifications are subject to change without notice. Functional descriptions and illustrations in this document may vary from your PS4™ system software and/or PS VR device software, depending on the version in use.

VR headset

Screen	1920 × RGB × 1080 (960 × RGB × 1080 per eye)
Sensor	6-axis motion sensing system (3-axis gyroscope, 3-axis accelerometer)
Port	Stereo headphone jack
External dimensions	Approx. 187 × 185 × 277 mm (width × height × depth / excluding projecting parts / at shortest headband length)
Mass	Approx. 600 g (excluding cables)
Operating temperature	5 °C to 35 °C

Processor unit

Input/output	HDMI TV port HDMI PS4 port (USB) port HDMI output port AUX port
Maximum rated power	Approx. 20 W
Input power rating	12 V ≈ 1.7 A
External dimensions	Approx. 150 × 39 × 114 mm (width × height × depth / excluding projecting parts)
Mass	Approx. 300 g
Operating temperature	5 °C to 35 °C

AC adaptor

Input	100-240 V ~ 1 A 50/60 Hz
Output	12 V ≈ 3 A
External dimensions	Approx. 108 × 46 × 30 mm (width × height × depth / excluding projecting parts)
Mass	Approx. 146 g

Supported video input signals

For information about supported video input signals, visit rd.playstation.com/psvr/zvr2/. You can also access this information by using the QR code.



HARDWARE WARRANTY

For warranty terms and conditions of respective regions, please refer to the "Support" page of the official website asia.playstation.com/, or call our Customer Service Hotline (→ "Further information").

Copyright and trademarks

"PS" and "PlayStation" are registered trademarks or trademarks of Sony Interactive Entertainment Inc.

"SONY" and "PS" are registered trademarks or trademarks of Sony Corporation.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

All other trademarks are the property of their respective owners.

Further information

Step-by-step setup video

Visit rd.playstation.com/psvr/zvr2/ to view a step-by-step setup video. You can also access the video using the QR code.



Support

The official site (see below) for PlayStation® product support provides the latest questions and answers about your product.

Official Website

asia.playstation.com/

Customer Service Hotline

Mon to Sun: 9:00-20:00

Hong Kong: 852-2241-2256

Singapore: 800-8523-663

Taiwan: 0809-079-888

CT

警告

使用本產品以前，請先詳細閱讀本使用說明書及對應產品的說明書，並請遵照各項安裝的警告及使用說明。請妥善保存，以備將來參考之用。

- 若您感覺暈眩、噁心、輕微嘔吐、噁心、不適，或因頭暈、暈物引起的身體搖晃不住，或感覺運動平衡或暈浪感時，請勿使用PlayStation™VR。若為患有重病者，使用PS VR的請先諮詢醫生。
- 戴上VR頭戴裝置後會阻擋您實際的周圍視線。VR頭戴裝置無法偵測障礙物。使用前，請在比遊戲空間更大的範圍內進行確認並清除障礙物。關於設置遊戲空間的方法，詳情請參閱快速參考指南中「關於遊戲空間」的部分。為避免發生受傷，請確認您周圍是否有可能導致碰撞或絆倒的牆壁、樓梯、家具或任何障礙物。
- 請事先做好預防其他人、寵物或障礙物在遊戲時進入遊戲空間的措施。
- 戴上VR頭戴裝置後，請留在遊戲空間的中央位置，並避免到處走動。同時請盡量坐著遊玩，避免過度或激烈的頭部、四肢或身體動作。若應用程式指示您在戴著VR頭戴裝置時站立，請小心遵照應用程式的指示。
- 開始使用前及遊玩時，請定期確認VR頭戴裝置線架沒有纏繞您的身體或四肢。

- 如果您或您的孩子有以下任何一種健康問題或狀況，請立即停止使用並諮詢醫生，才能繼續遊玩遊戲：暈眩、視覺障礙、眼睛或肌肉抽動、意識不清、精神恍惚、突發性疾病或不由自主的動作或肌肉抽動。必須經醫生許可才能繼續遊玩遊戲。
- 有些人可能會感覺噁心、噁心、意識不清、視覺模糊或其他不適。若您感到不舒服，請立即停止使用並卸下VR頭戴裝置。請休息並避免從事任何需要在正常視力、平衡或協調狀態下進行的活動，直至不適感消除。
- 請勿在疲勞或需要睡眠時使用本產品。
- 請勿在可能產生搖晃或不穩定的場所使用本產品。
- 過度虛擬實境效果可能需要一些時間。建議初期使用本產品時，每次時間不要過長。
- 一般建議每天1小時休息1分鐘。但觀看虛擬實境效果的內容時，休息的時間間隔可能會因人而異。請充分休息以讓任何不適感消滅。
- 使用後若感覺不適，請休息至不適感消滅。

光刺激誘發的癲癇（光敏性癲癇）

若您有癲癇狀況或曾經癲癇發作，遊玩前請諮詢醫生。有些人看到閃光或流光，或是遊玩遊戲時電視機出現其他光線刺激，可能會產生眼瞼痙攣、視力失調、偏頭痛、肌肉抽動、抽跳、暫時性眼前冒黑、失去意識或迷失方向等症狀。若您有在遊玩時出現上述任何一項症狀，請立即停止使用並諮詢醫生。

若您感到下列症狀時請立即停止遊玩：除上述症狀以外，遊玩時您感覺噁吐、噁心、噁心、無力、類似暈車感，或感到有一部位如眼睛、耳朵、手、手臂、腳感覺不適，請立即停止使用。若症狀持續，請諮詢醫生。

裝置軟件

PS VR的裝置軟件乃受個別終端使用授權承諾條款限制授權。詳情請參閱以下網站：doc.ci.playstation.net/doc/psvr-eula/

以下規定僅適用於台灣

使用態度應書寫權力
使用年月：請參閱本體標示
製造號碼：請見產品本體標示

設備名稱：PlayStation™VR頭戴裝置，型號（型）：CUH-ZVR2						
	限用物質及其化學符號					
單元	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr+6)	多環芳烴 (PBB)	多環二芳烴 (PBDE)
頭戴裝置單元殼體	-	○	○	○	○	○
訊號處理器單元殼體	-	○	○	○	○	○
線路板	-	○	○	○	○	○
有機發光二極體	-	○	○	○	○	○
鏡頭	-	○	○	○	○	○
發光二極體	-	○	○	○	○	○
其他附件（交流電轉換器等）	-	○	○	○	○	○

備考1、超出0.1 wt % 及“超出0.01 wt %”係指限用物質之百分比含量

備考2、“○”係指該項限用物質之百分比含量未超出百分比含量基準值。

備考3、“-”係指該項限用物質為排除項目。

使用前須知事項

關於安全

- 請勿損壞交流電線路及交流電轉換器。
- 關於產品的安全與支援的詳細資訊，請瀏覽官方網站 (→ "更多資訊")。

使用與保養

- 連接前請確認端子沒有任何灰塵或細微異物。
- 請勿抓取連接線來動用VR頭戴裝置或交流電轉換器。
- 追蹤燈 (→ "各部名稱") 熄滅前，請勿拆除VR頭戴裝置線。若在訊號增強時拆除或拆除，可能會造成故障。
- 請勿在本產品上放置其他物品。並請勿投擲或掉落本產品，或使其受到強烈外力衝擊。
- 請將本產品放在兒童拿不到的地方保管。兒童可能會該否小零件或拉扯連接線而使訊號處理器或VR頭戴裝置滑落，或會用連接線纏繞自己，而導致受傷或意外發生、意識故障。
- 請勿在雷雨天氣中觸摸交流電線路、交流電轉換器或訊號處理器。
- 請勿讓液體、小零件或其他異物掉入本產品 (如連接埠或風扇)。若若有液體或異物掉入您的設備中，請從電源插座拔除連接器。
- 請勿將本產品暴露在灰塵、煙霧或蒸氣中。灰塵或其他異物可能會引起火災或燒傷電。
- 請勿讓身體長時間接觸使用中的訊號處理器、交流電轉換器或從通風孔所排出的氣團。長時間接觸這些可能導致低溫灼傷。
- * 低溫灼傷是指皮膚長時間接觸低溫物體 (40 °C或以上) 所造成的灼傷。
- VR頭戴裝置、立體聲耳機或立體聲耳機組對皮膚造成不適時請停止使用。若耳殼磨損或耳殼組對您的皮膚造成不適，請立即停止使用。停止使用後，若您依舊沒有改善，請立即就醫。
- 本產品及零件使用金屬或塑膠製造。若要丟棄本產品，請遵照當地法規正確處理。
- 請遵照以下使用說明，以避免產品外殼變形或变色。
 - 請勿在本產品上使用溶劑或其他化學劑。
 - 請勿讓橡膠或乙烴基材料長時間接觸本產品。
- 若使用耳機組或耳機時請盡量避免將音量調整過高。請將音量調整至安全水平。持續聆聽一段時間後，即使音量不斷增大的導聆聲音，聽起來可能會有一些異質，但實際上卻可能導致聽覺。若您感到耳鳴或耳不適，或出現口齒不清的情況，請立即停止使用耳機組或耳機，並諮詢醫生檢查聽覺。音量越高，會越快對聽覺造成影响。為保護聽覺：
 - 使用耳機組或耳機時請盡量避免將音量調整過高。
 - 避免調高音量至引起耳痛的聲音。
 - 若耳殼磨損或耳殼組對您的皮膚造成不適，請調低音量。
- 當在空氣乾燥的氣候下使用耳機組或耳機時，耳朵可能會感到輕微但短暫的（靜電）觸電。此情形並非耳機組或耳機發生故障，而是人體內累積靜電所造成。

關於兒童使用

未滿12歲的兒童請勿使用此VR頭戴裝置。

配戴VR頭戴裝置

- 在您使用VR頭戴裝置時，正確配戴是非常重要的。
 - 若您確認如何配戴頭戴裝置，請到PlayStation®4主機的機能畫面，選 (設定) > [感應裝置] > [PlayStation VR]。
 - 請勿隨意旋緊調整按鈕 (→ "各部名稱")。
 - 當您戴著頭戴時仍可配戴VR頭戴裝置，但調整頭戴時請小心 (→ "各部名稱")。若您的眼鏡碰撞到VR頭戴裝置的鏡片，可能會造成眼鏡、鏡片或兩者發生損壞。請勿過向內或向外調整眼鏡位置。
- 戴上後，請定期確認VR頭戴裝置是否配戴舒適以確保配戴方法正確。

VR頭戴裝置螢幕

請勿讓VR頭戴裝置的鏡片 (→ "各部名稱") 受到日光或強光直射。否則可能會損壞VR頭戴裝置螢幕及導致視網膜受損。

- 請不要讓任何障礙物阻礙VR頭戴裝置的安裝測試器 (→ "各部名稱")。若安裝測試器受到阻礙，即使卸下頭戴裝置，螢幕也會自動關閉。若讓螢幕長時間顯示圖像，可能會導致影像模糊，使螢幕永久留下模糊殘像。

螢幕分合位置可能會出現黑點或持續發亮的黑點，此屬於螢幕的正常現象並非故障。螢幕採用高精密密度技術製作，但每個螢幕都可能會發生看到非常小的黑點或經常發亮的黑點出現，或是顏色濃度、明亮程度不一的情況。

切勿分解、改造本產品或附屬品

使用本產品與附屬品時請務必遵守本使用說明書所記載的指示說明。嚴禁擅自分解本產品，並禁止分解和使用其零件組構。擅自分解產品將損失所有保證權益。此外，若分解或改造本產品，可能會引起火災、觸電或故障的危險。

結露現象

若把PS VR從寒冷的地方直接搬到溫暖的場所，VR頭戴裝置及訊號處理器內可能會凝結水氣。此現象可能會導致產品無法正常運作。此時，請關閉VR頭戴裝置的電源並從電源插座拔除交流電線路。水氣尚未蒸發時，切勿用布來拭。 (為避免造成其他損傷，若產品仍無法恢復正常，請瀏覽官方網站 (→ "更多資訊")。)

遮光器

從VR眼鏡裝置取下遮光器，並用清水清洗。用柔軟的布擦拭至完全乾燥，然後重新裝到頭戴裝置上。

將遮光器上突起的部分對準VR眼鏡裝置上的1個小孔以重新裝上。

	
제품을 사용할 거 전에 본 사용설명서와 대응 헤드웨어의 사용설명서를 잘 읽어보신 후 실습을 위한 안내와 경고 사항을 지켜 주십시오. 읽어보신 후에는 찾기 쉬운 곳에 보관해 주십시오.	
<ul style="list-style-type: none">피로, 어지러움, 구역질, 두통이 일어나 알코올이나 약에 대한 상태이나나 움직임이나 균형감각에 문제가 있다고 느껴질 때는 PlayStationVR을 사용하지 마십시오. 지병이 있거나 건강이 좋지 않은 경우 PS VR을 사용하기 전에 의사와 상담 해 주십시오. VR headset을 사용하면 주위가 보이지 않게 됩니다. VR 헤드셋은 주위의 경계를 잘 감지하지 못합니다. 착용하시기 전에 플레이어 영역 주변에 장애물이 될 수 있는 사물을 지워 충분한 공간을 확보해 주십시오. 플레이 영역에 대한 자세한 사항은 빠른 시작 가이드의 ‘플레이 영역에 대하여’를 참조해 주십시오. 부딪히거나 넘어 일어날 수 있는 책이나 개단, 가구, 장래물 등이 잘리지 확인해 주십시오. 사람 중에 플레이하는 공간에 다른사람이나, 사람, 기타 장애물이 들어오지 않도록 공간의 안전 확보를 해 주십시오. 플레이어 영역의 가운데에 있도록 하고 VR 헤드셋을 착용한 채로 멀리 다니다 마십시오. 가능한 한 언어서 제할해 주시고 VR 헤드셋을 착용중에는 머나날, 팔, 다리의 과도한 움직임을 자제해 주십시오. 특정 애플리케이션을 서서 이용해서 하는 경우, 애플리케이션의 안내를 잘 따라 주십시오. 플레이어를 시작하기 전에 VR 헤드셋의 케이블이 풀리거나 녹, 필드리에 감기지 않았는지 확인하시고, 플레이 중에도 자주 확인해 주십시오. 불이나나 재나기 아래와 같은 문제가 발생할 수 있다면 즉시 사용을 중지해 주십시오. 어지러움, 시야 흐리짐, 눈이나 근육 경련, 의식장애(실신), 방향감각 상실, 발작, 또는 불수의 동요이나 감기, 게임 플레이 재개를 위해서는 의사의 승인을 받아 주십시오. 간혹 열미, 맥스감을, 방향감각 상실, 시야 흐리짐이나 기타 불편감을 경험하는 경우가 있습니다. 이런 증상을 느끼면 즉시 사용을 중지하고 VR 헤드셋을 벗어 주십시오. 휴식을 취하고 손상되지 않은 시간, 균형, 호흡이 필요한 활동은 증상 이 완전히 사라질 때까지 피해 주십시오. 피로하거나 수면 부족인 상태로 사용하지 마십시오. 호흡음이 발생할 수 있는 강한 장소에서는 사용하지 마십시오. 가상 현실 경험에 익숙해지려한 시간이 길수록 수 있습니다. 처음 사용할 때는 짧은 시간 동안 사용하지를 권합니다. 일반적으로 한 시간이나 15분 휴식을 취해주시기를 권합니다. 가상 현실 콘텐츠를 볼 때 필요한 휴식 시간의 길이나 빈도는 개인에 따라 다르므로 불편한 느낌이 완전히 사라질 때까지 충분한 휴식을 취해 주십시오. 사용 후에 불편한 증상이 있을 때는 충분한 휴식을 취해 주십시오.	

通風孔

請用吸塵器等清除堆積的灰塵。

耳塞

從主體耳機組上取下耳塞，使用以清水稀釋的中性清潔劑進行手洗，接著將軟布擦拭至完全乾燥，再重新裝上。關於取下耳塞的方法，請閱覽「更換耳塞」。

規格

本公司保留在沒有事先通知的情況下，變更設計或規格的權利。本說明書中介紹的功能與圖像，可能因您使用的PS4™主機之系統軟件，及 / 或PS VR之裝置軟件版本不同後，而與實際不同。

	
	
형식	1920 × RGB × 1080 (左右視野角90° × RGB × 1080)
센서器	6軸動態感應系統 (3軸旋轉轉軸, 3軸加速度計)
連接埠	立體聲耳機連接埠
外觀尺寸	約187 × 185 × 277 mm (寬×高×深 / 不包括突起部分) / 頭帶最短長度
重量	約600 g (不包括繩)
操作溫度	5℃–35℃

	
	
輸入 / 輸出	HDMI TV連接埠 <div> <div>HDMI PS4連接埠</div> <div>(USB)音源埠</div> <div>HDMI輸出連接埠</div> <div>AUX連接埠</div></div>
最大額定電力	約20 W
額定電壓，額定輸入電流	12 V 1W 1.7 A
外觀尺寸	約150 × 39 × 114 mm (寬×高×深 / 不包括突起部分)
重量	約300 g
操作溫度	5℃–35℃

	
輸入	100–240 V~1 A <div> <div>50/60 Hz</div></div>
輸出	12 V 1W 3 A
外觀尺寸	約108 × 46 × 30 mm (寬×高×深 / 不包括突起部分)
重量	約146 g

支援的影像輸入訊號

關於支援的影像輸入訊號，請前往rd.playstation.com/psvr/zvr2/。您亦可從QR代碼前往查看相關資訊。



硬件保用

有關各地區的用條款及細則，請瀏覽官方網站asia.playstation.com/的「支援」頁面，或致電客戶服務熱線（↗「更多資訊」）。

版權與商標

“**LD**”和“PlayStation”為Sony Interactive Entertainment Inc.之註冊商標或商標。

“SONY”和“Ⓜ”為Sony Corporation之註冊商標或商標。

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

所有其他商標均屬相關原作者版權人所有。

更多資訊

	
請到rd.playstation.com/psvr/zvr2/觀看指南影片確認連接方法。您亦可從QR碼存取網址。	
	

支援

官方網站（見下文）的PlayStation®產品支援網頁，提供產品的最新常見問題和解答。

官方網站

客戶服務熱線
週一至週日：9:00-20:00
香港 : 852-2341-2356
新加坡 : 800-8523-663
台灣 : 0809-079-688 (限市話) / (02)2735-5398

절대 제품이나 액세서리를 분해 또는 개조하지 마십시오

제품 및 액세서리는 본 사용설명서의 안내에 따라 사용해야 합니다. 제품에 대한 분석 및 개조, 회로 설정에 대한 분석 및 사용은 금지되어 있습니다. 제품을 분해하면 제품의 보증이 무효화됩니다. 또한 분해, 개조된 제품은 화재 및 감전, 고장의 위험이 있습니다.

KR

경고

- 제품을 사용하기 전에 본 사용설명서와 대응 헤드웨어의 사용설명서를 잘 읽어보신 후 실습을 위한 안내와 경고 사항을 지켜 주십시오. 읽어보신 후에는 찾기 쉬운 곳에 보관해 주십시오.
- 피로, 어지러움, 구역질, 두통이 일어나 알코올이나 약에 대한 상태이나나 움직임이나 균형감각에 문제가 있다고 느껴질 때는 PlayStationVR을 사용하지 마십시오. 지병이 있거나 건강이 좋지 않은 경우 PS VR을 사용하기 전에 의사와 상담 해 주십시오.
- VR headset을 사용하면 주위가 보이지 않게 됩니다. VR 헤드셋은 주위의 경계를 잘 감지하지 못합니다. 착용하시기 전에 플레이어 영역 주변에 장애물이 될 수 있는 사물을 지워 충분한 공간을 확보해 주십시오. 플레이 영역에 대한 자세한 사항은 빠른 시작 가이드의 ‘플레이 영역에 대하여’를 참조해 주십시오. 부딪히거나 넘어 일어날 수 있는 책이나 개단, 가구, 장래물 등이 잘리지 확인해 주십시오.
- 사람 중에 플레이하는 공간에 다른사람이나, 사람, 기타 장애물이 들어오지 않도록 공간의 안전 확보를 해 주십시오.
- 플레이어 영역의 가운데에 있도록 하고 VR 헤드셋을 착용한 채로 멀리 다니다 마십시오. 가능한 한 언어서 제할해 주시고 VR 헤드셋을 착용중에는 머나날, 팔, 다리의 과도한 움직임을 자제해 주십시오. 특정 애플리케이션을 서서 이용해서 하는 경우, 애플리케이션의 안내를 잘 따라 주십시오.
- 플레이어를 시작하기 전에 VR 헤드셋의 케이블이 풀리거나 녹, 필드리에 감기지 않았는지 확인하시고, 플레이 중에도 자주 확인해 주십시오.
- 불이나나 재나기 아래와 같은 문제가 발생할 수 있다면 즉시 사용을 중지해 주십시오. 어지러움, 시야 흐리짐, 눈이나 근육 경련, 의식장애(실신), 방향감각 상실, 발작, 또는 불수의 동요이나 감기, **게임 플레이 재개를 위해서는 의사의 승인을 받아 주십시오.**
- 간혹 열미, 맥스감을, 방향감각 상실, 시야 흐리짐이나 기타 불편감을 경험하는 경우가 있습니다. 이런 증상을 느끼면 즉시 사용을 중지하고 VR 헤드셋을 벗어 주십시오. 휴식을 취하고 손상되지 않은 시간, 균형, 호흡이 필요한 활동은 증상 이 완전히 사라질 때까지 피해 주십시오.
- 피로하거나 수면 부족인 상태로 사용하지 마십시오.
- 호흡음이 발생할 수 있는 강한 장소에서는 사용하지 마십시오.
- 가상 현실 경험에 익숙해지려한 시간이 길수록 수 있습니다. 처음 사용할 때는 짧은 시간 동안 사용하지기를 권합니다.
- 일반적으로 한 시간이나 15분 휴식을 취해주시기를 권합니다. 가상 현실 콘텐츠를 볼 때 필요한 휴식 시간의 길이나 빈도는 개인에 따라 다르므로 불편한 느낌이 완전히 사라질 때까지 충분한 휴식을 취해 주십시오.
- 사용 후에 불편한 증상이 있을 때는 충분한 휴식을 취해 주십시오.

빛의 자극으로 인하여 일어나는 발작에 대하여

간질이나 발작 등의 증상이 있는 분은 플레이하기 전에 의사와 상담해 주십시오. 간혹 TV 화면이나 비디오 화면이 깜빡일 때 발작이 발생할 수 있습니다. 그 외 빛의 자극에 의 해 눈의 황혼, 시야 흐리짐, 먼투물, 근육 경련, 경기, 실신, 방향감각 상실 등의 증상이 일어나는 경우가 있습니다. 플레이 중에 이런 증상을 경험한 분은 즉시 사용을 중지하고 의사와 상담해 주십시오.

이런 경우에는 즉시 사용을 중지해 주십시오:

일 증상이 다해 플레이 중에 두통, 어지러움, 맥스감을, 피로, 멀미와 비슷한 증상을 느끼거나 눈, 귀, 손, 팔, 다리와 같은 신체 일부에 불편감이나 통증을 느끼면 즉시 사용을 중지해 주십시오. 사용을 중단해도 나아지지 않을 때는 의사의 진찰을 받으십시오.

다바이스 소프트웨어에 대하여

PS VR에 탑재되는 다바이스 소프트웨어는 개별 유저 라이선스 이용권에만 따릅니다. 자세한 내용은 doc.cd.playstation.net/doc/psvr-eula를 참조해 주십시오.

사용전 주의 사항

안전

- AC 전원 코드나 AC 어댑터가 손상되지 않도록 주의해 주십시오.
- 제품의 안전 및 고객센터에 대한 자세한 사항은 저희 웹사이트(↗ "추가 정보")를 참조해 주십시오.

사용 및 관리

- AC 전원 코드나 AC 어댑터가 손상되지 않도록 주의해 주십시오.
- 제품의 안전 및 고객센터에 대한 자세한 사항은 저희 웹사이트(↗ "추가 정보")를 참조해 주십시오.
- 연결할 때에는 단자부에 먼지나 이물질이 묻어있지 않은지 확인해 주십시오.
- VR 헤드셋 및 AC 어댑터를 케이블을 잘고 휘두르지 마십시오.
- VR 헤드셋 케이블은 트래킹 라이트(↗ "각부 명칭")가 꺼져 있을 때 분리해 주십시오. 트래킹 라이트가 꺼져 있을 때 분리하면 고장의 원인이 됩니다.
- 무거운 물체를 옮기거나, 던지거나, 밀어뜨리거나 발 등 강한 충격을 가하지 마십시오.
- 주야의 손이 닿지 않는 곳에 두어 주십시오. 작은 부품을 실수로 삼키거나 케이블을 잡아 당겨 프로세서 유닛이나 VR 헤드셋이 떨어지거나, 케이블을 묶어 감는 등 사고나 부상, 고장의 원인이 됩니다.
- 청동번개가 치면 AC 전원 코드, AC 어댑터 및 프로세서 유닛에 손대지 마십시오.
- 제품 내부(단자, 환풍구 등)에 물이나 이물질이 들어가지 않도록 주의해 주십시오. 물이나 이물질이 들어갔을 때는 즉시 사용을 중지하고 콘센트를 뽑아 주십시오.
- 그늘음이나 수증기, 습기나 먼지, 담배 연기기 많은 곳에 두지 마십시오. 화재나 감전의 원인이 될 수 있습니다.
- 전원이 꺼진 상태로 프로세서 유닛이나 AC 어댑터를 장시간 던지거나 흔기기에 쓰러오는 바람을 장시간 쬐지 마십시오. 저온 확산의 원인이 될 수 있습니다.
 - 저온 확산이란 비교적 낮은 온도(약 40℃ 이상)의 물체에 장시간 파우가 덮인 채로 있을 때 일어나는 화학 등을 말합니다.
- VR 헤드셋이나 스테레오 헤드폰, 스테레오 헤드셋이 피부에 닿지 않을 때는 사용하지 마십시오. 피부에 닿지 않는다는 생각이 들 때는 즉시 사용을 중지해 주십시오. 헤드셋이나 헤드폰의 사용을 중지해도 나아지지 않을 때는 의사의 진단을 받아 주십시오.
- 제품 및 부품은 금속과 플라스틱으로 만들어져 있습니다. 제품을 떼기하실 때는 각 지방 자치단체에서 정한 폐기 규정에 따라 주십시오.
- 제품의 표면이 변질, 변색되지 않도록 다음 사항을 지켜 주십시오.
 - 술벤트나 기타 화학작용을 사용하지 마십시오.
 - 고무나 비닐 제품을 장시간 접촉시키지 마십시오.
- 헤드셋을 큰 소리로 장시간 계속해서 들으면 청력 손실을 가져올 수 있습니다. 먼 강한 음향으로 설정해 주십시오. 오랜 시간 큰 소리로 들으면 청력 손실의 위험을 감소시켜 주십시오. 청력 손실이란 청력에 손상될 줄 수 있습니다. 소리가 울리는 것처럼 느껴지거나 알스리가 작게 들리면 듣기를 멈추고 청력을 확인해 주십시오. 음향 발 크게 들을수록 청력이 더 빨리 영하함을 받게 됩니다. 청력을 보호하기 위해서 는:
 - 헤드셋을 높은 음량으로 들는 시간을 제한하십시오.
 - 주변의 시끄러운 소리를 차단하기 위해 헤드폰을 놓이지 마십시오.
 - 주변 사람의 이야기 소리를 들을 수 없다면 음량을 낮추십시오.
 - 공기가 건조한 때에 헤드셋이나 헤드폰을 사용하면부터 귀에 끼워하는 통증을 느끼는 경우가 있습니다. 이는 인체에 축적된 진균이로 인한 것으로 헤드폰 또는 헤드셋의 고장에 의한 것이 아닙니다.

사용 연명에 대하여

PS VR의 사용 연명은 12세 이상입니다.

VR 헤드셋의 착용에 대하여

- 바른 착용 상태로 사용해 주십시오.
 - 착용 방법은 PS4™의 기능 화면에서 (설정) > [주변기기] > [PlayStation VR]을 선택하면 확인할 수 있습니다.
 - 조절 다이얼(↗ "각부 명칭")을 너무 바짝 죄지 않도록 주의해 주십시오.
 - VR 헤드셋은 안경을 쓴 채로 착용할 수 있습니다. 스크린(↗ "각부 명칭")의 위치를 조절하실 때는 안쪽 렌즈와 안경이 부딪치지 않도록 주의해 주십시오.
- 착용한 후 장기적으로 착용감을 확인해 주십시오.

VR 헤드셋 화면에 대하여

- VR 헤드셋의 렌즈(↗ "각부 명칭")에 직사광선이나 강한 빛이 닿지 않도록 주의 해 주십시오. VR 헤드셋 화면이 변질되어 고장의 원인이 됩니다.
- PS VR의 광학 센서(↗ "각부 명칭")가 가려지면 안도록 확인해 주십시오. 광학 센서가 가려진 상태에서 VR 헤드셋을 벗어 플레이 사용은 금지되어 있습니다. 장시간 같은 화면이 표시되어 있으면 이미지의 흔적이 남아 화면에 잔상이 남을 수 있습니다.
- 스크린은 고도의 정밀 기술로 만들어졌으나 간혹 불이 들어오지 않는화소나 항상 불이 들어와 있는 화소가 보이거나 색이나 밝기가 얼룩져 보이는 경우가 있습니다. 또한 진원을 찾을 때 몇 초간 화면이 흔들리는 경우는 있습니다. 이런 경우는 고장이 아닙니다.

이슈및팅(결로현상)이 일어났을 때에는

PS VR을 찬 곳에서 따뜻한 상태로 옮긴 직후에는 VR 헤드셋 마이크로세서 유닛 부에 이슬이 맺히(결로) 바르게 작동하지 않는 경우가 있습니다. 결로 현상이 일어나올 때에는 VR 헤드셋의 전원을 끄고, AC 전원 코드의 플러그를 뽑은 상태로 몇 시간 동안 방치해 주십시오. 옆서서와 같이해도 정상으로 작동하지 않는 경우에는 고객센터사이트(↗ "추가 정보")를 참조해 주십시오.

이상하게 동작하거나 조작할 수 없는 경우에는

VR 헤드셋의 (전원) 버튼(↗ "각부 명칭")을 7초 이상 눌러서 강제종료한 후, 전원을 켜 주십시오. 그릴해 헤드도 나아지지 않을 때는 PS4™를 재기동해 주십시오.

온도 상승 메시지가 표시된 경우에는

프로세서 유닛 내부가 뜨거워질수 있습니다. 고온인 장소에서 사용하거나 환풍구가 막힌 상태로 사용하고 있지 않았는지 확인해 주십시오. 그대로 계속 사용하면 심각 할 수 없게 됩니다. PS4™의 광학 센서 후 잠시 두었다가 다시 전원을 켜 주십시오.

- 제품을 패시브 케이블이나 열이 빠져나갈 수 있는 곳에서 사용하지 마십시오.

AC 어댑터 및 AC 전원 코드의 사용에 대하여

- 온도가 있을 때 즉시 AC 전원 코드를 뽑을 수 있도록 권원은 손쉽게 뽑을 수 있는 쪽을 사용해 주십시오. 제품의 작동이 이상하거나 이상한 소리가 날때가 나타나거나 너무 뜨거운 경우 사용을 중지하고 AC 전원 코드를 콘센트에서 뽑은 후 즉시 다른 케이블로 분리해 주십시오.
- AC 전원 코드의 플러그는 프로세서 유닛의 상단 표시등에 빨간색 불이 켜져 있을 때 콘센트에서 빼 주십시오. 상단 표시등에 흰색 불이 켜져 있을 때나 빨간색 불이 깜빡이고 있을 때 빠른 고장의 원인이 됩니다.
- 동봉된 AC 어댑터와 AC 전원 코드 이외의 제품을 사용하지 마십시오. 동봉된 AC 어댑터와 AC 전원 코드는 본 기기에만 사용할 수 있는 전용 제품입니다. 다른 제품에는 사용할 수 없습니다. 또한 다른 AC 어댑터나 AC 전원 코드를 본 기기에 사용하지 마십시오. 이 주의 사항을 지키지 않으면 제품 고장의 원인이 될 수 있고 고장발생감으로 이어질 수 있습니다.
 - HDMI™ 케이블을 연결한 후 AC 전원 코드를 콘센트에 연결해 주십시오.
- 절든 온수로 AC 전원 코드를 만지지 마십시오.
 - AC 어댑터를 찬 천으로 덮은 채로 사용하지 마십시오. 괴멸되어 화재 및 고장의 원인이 됩니다.
 - 손질하기 전이나 장기간 본 기기를 사용하지 않을 때는 AC 전원 코드를 콘센트에서 뽑아 주십시오.
 - 벌집이나 DC/AC 인터타를 사용하지 마십시오.

보관에 대하여

- 제품 및 액세서리를 보관하시거나 직사광선이 닿는 곳에 두지 마십시오.
- 제품 및 액세서리를 보관하시거나 기울어진 곳, 진동부 발생하는 곳에 두지 마십시오.

PS VR에 대하여

- PS VR은 PS4™와 PlayStation Camera를 함께사용함으로써 가상 현실을 즐길 수 있습니다. 플레이어가 착용한 VR 헤드셋의 위치나 방향, 움직임을 카메라가 읽어들이어 직간접적인 조차를 실현합니다.
- PS4™의 시스템 소프트웨어 및 PS VR의 다바이스 소프트웨어는 항상 최신 버전으로 업데이트하여 사용해 주십시오.
- VR 헤드셋을 사용하시려면 CUH-ZVR2에 동봉된 프로세서 유닛에 연결해 주십시오. CUH-ZVR1의 프로세서 유닛에는 연결하여 사용할 수 없습니다.

VR 헤드셋 사용 시의 자세에 대하여

VR 헤드셋은 안은 상태로 사용하지기를 권합니다. 콘센트에따라서는 신 자세로 사용하는 것도 있습니다. 그러한 경우에는 안전을 충분히 고려해 주십시오.

PS VR 설정하기

PS4™의 기능 화면에서 (설정) > [주변기기] > [PlayStation VR]을 선택 한 후 설정할 항목을 선택합니다.

앞이두기

- 이 설정은 PS4™에 PS VR을 접속하고 있을 때만 표시됩니다.
- 일부 항목은 (ON)(PS) 버튼을 1초 이상 누르고 있을 때 표시되는 빠른 메뉴에서도 설정할 수 있습니다.
- PS VR의 설정 방법에 대한 자세한 사항은 PS4™의 사용자 가이드를 참조해 주십시오. 기능 화면에서 (설정) > <PS>(사용자 가이드)유닛설정 > <PS>(사용자 가이드)를 선택합니다.


보호자에 의한 이용 제한에 대하여

자녀가 PS4™를 사용하는 경우, 보호자 가 필요에 따라 VR 헤드셋의 이용을 제한할 수 있습니다. 기능 화면에서 (설정) > [자녀보호기능/제한]관리를 선택한 후 자녀별로 설정해 주십시오.

각부 명칭


VR 헤드셋

앞면





- A) 트래킹 라이트(양면)
 - 뒤쪽의 불이 피라넥트로 켜짐：전원 켜짐
 - 앞면의 불이 피라넥트로 켜짐：VR 모드 중 불 꺼짐：　　전원 꺼짐
- B) 스크로 조정 버튼
- C) 전원 헤드패드
- D) 후면 헤드패드
- E) HDMI 커넥터
- F) AUX 커넥터
- G) 스크프

뒷면



- A) 헤드밴드
- B) 광학 센서
- C) 렌즈
- D) 조절 다이얼
- E) 헤드밴드 릴리스 버튼
- F) 트래킹 라이트(양면)
- G) 이어피스 홀더

옆면



- A) 스테레오 헤드폰 단자
- B) 헤드 고정부 홀
- C) (전원) 버튼
- D) 빛 가리개
- E) 이어피크
- F) 트래킹 라이트(양면)
- G) 음향 + 버튼
- H) (이어피크 음소거) 버튼
- I) 음향 + 버튼


프로세서 유닛

앞면




- A) 상태 표시등
 - 흰색 불 켜짐：전원 켜짐
 - 빨간 불 켜짐：대기 모드
- B) AUX 단자
- C) HDMI 출력 단자

뒷면



- A) HDMI TV 단자
- B) HDMI PS4 단자
- C) (USB) 단자
- D) DC IN 12V 단자
- E) 각기구


스테레오 헤드폰



- A) 이어피스
- B) 스테레오 헤드폰 플러그
- C) 고정핀

이어피스 교환하기

귀에 시 스테레오 헤드폰에는 M 사이즈의 이어피스가 부착되어 있습니다. 크기가 구에 맞지 않는 노즐이 들면 동봉된 S 사이즈나 L 사이즈로 교환해 주십시오. 교환하실 때는 이어피스를 돌리면서 벗기 주십시오.



앞이두기

이어피스를 부착하실 때는 사용중에 벗기지 않도록 확실히 끼워 넣어 주십시오.

손질에 대하여

- 제품을 닦거나 관리할 때 아래의 안내에 따라 주십시오.
 - 안전에 위해, 손질할 할 경우에는 AC 전원 코드의 플러그를 콘센트에서 뽑아 주십시오.
- 제품 외부의 오염을 제거할 때 술벤트나 기타 화학작용을 사용하지하십시오.
- 제품을 닦을 때 희석된 청소용 알코올로 닦지 마십시오.

프로세서 유닛의 표면, VR 헤드셋의 표면,패드, 단자류

부드러운 마른 천으로 닦아 주십시오.

앞이두기

렌즈


렌즈 진공의 부드러운 마른 천으로 닦아 주십시오. 종이 타월 같은 종이 제품이나 렌즈를 닦는 용도가 아닌 티슈를 사용하지 마십시오.

앞이두기

렌즈에 붙어있거나 오염이 묻은 렌즈 방치하면 변질되거나 기가 떨어질 수 있습니다.

빛 가리개

VR 헤드셋에서 빛 가리개를 분리하여 벗겨 주십시오. 부드러운 천으로 물기를 닦고 잘 말린 후 VR 헤드셋의 13공데 구멍에 빛 가리개의 돌기를 맞춰 고정해 주십시오.



황기구

먼지가 쌓여 있을 때에는 청소기 등으로 먼지를 제거해 주십시오.

이어피스

스테레오 헤드폰에서 이어피스를 분리한 후 최대한 청정상태로 씻어 주십시오. 부드러운 천으로 물기를 닦은 후 잘 건조하여 다시 부착해 주십시오. 이어피스의 올바른 방법에 대해서는 ‘이어피스 교환하기’를 참조해 주십시오.

주요 사양

디자인 및 사양은 예고없이 변경될 수 있습니다.

본 문서에 기재된 초장 설명 및 화면은 PS4™의 시스템 소프트웨어 및 PS VR의 다바이스 소프트웨어 버전에 따라 다를 수 있습니다.

VR 헤드셋

스크린	1920 × RGB × 1080 (좌우의 눈 각각에 960 × RGB × 1080의 영상을 표시)
센서	6축 감각 시스템 (3축 자이로, 3축 가속도)
단자	스테레오 헤드폰 단자
크기	약 187 × 185 × 277 mm (가로 × 높이 × 세로, 최대 돌출부 제외, 헤드밴드 길이 포함일 때)
무게	약 600 g (메이플 제외)
허용 온도	5℃–35℃

프로세서 유닛

입출력	HDMI TV 단자 <div> <div>HDMI PS4 단자</div> <div>USB 단자</div> <div>HDMI 출력 단자</div> <div>AUX 단자</div></div>
최대 소비 전력	약 20 W
전원	12 V 1W 1.7 A
크기	약 150 × 39 × 114 mm (가로 × 높이 × 세로, 최대 돌출부 제외)
무게	약 300 g
허용 온도	5℃–35℃

AC 어댑터

입력	100-240 V~1 A <div> <div>50/60 Hz</div></div>
출력	12 V 1W 3 A
크기	약 108 × 46 × 30 mm (가로 × 높이 × 세로, 최대 돌출부 제외)
무게	약 146 g

대형 정보는 영상 입력 신호에 대하여

최신 정보는 아래의 웹사이트를 참조해 주십시오. QR 코드로도 접속할 수 있습니다. rd.playstation.com/psvr/zvr2/



AS

- 보증 기간은 구입일로부터 1년입니다.**
- 소비자 기본법에 의한 분쟁해결 기중에 존함니다.**
- 보증 기간 중 정상적인 사용 상태(사용설명서 등의 주의 사항에 따라 바르게 사용한 상태)에서 고장발생 경우에는 당사에서 무료로 수리해 드립니다.**

교환/수리에 대하여

- 고장 제품을 함께 보내주신 통령품은 돌려드리지 못할 수도 있습니다. 고객님의 제품 구입 후에 발생할 품질(데이터) 등은 재확인 후 보내 주십시오.
- 보내주신 제품은 당시의 판단에 따라 교환 및 수리 서비스를 제공합니다. 교환의 경우 리퍼해서 제품으로 교환될 수 있습니다.